


GRILL PARTS

For Models: KFRS361TSS00
(Stainless Steel)

36" CARTED GRILL



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GRILL PARTS


For Models: KFRS361TSS00
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	20	W10128635	Bracket, Panel	42	W10128761	Switch, Light
	W10110725	Use & Care Guide			Right	43	W10136433	Panel, Control
	W10110730	Conversion Instr. (LP to Natural)	21	W10128636	Bracket, Warming Rack	44	W10128763	Harness, Wire Control
2	W10128611	Rack, Warming	22	W10128637	Cover, Access Panel	45	W10128764	Valve, Main Brnr
3	W10136417	Grate, Large	23	W10128638	Clip, Wire	46	W10128766	Valve, Rear Brnr
4	W10128616	Grate, Small	24	W10136420	Hood Assy	47	W10128767	Igniter, Main Gas
5	W10128618	Plate, Sear	25	W10128640	Hole Plug	48	W10128768	Manifold
6	W10128619	Cover, Rear	26	W10128642	Panel, Side Left	49	W10128769	Baffle, Front
7	W10128620	Panel, Rear	27	W10128644	Bracket, Grease Tray (Right)	50	W10128770	Electrode
8	W10128621	Electrode, Rear Burner	28	W10128655	Roller, Drip Tray		W10136434	Main Burner
9	W10128622	Thermocouple, Rear, Burner	29	W10128656	Drip Tray Assy (Includes Rollers)	51	W10128771	Side Panel, Right
10	W10128623	Flex Tube, Rear Burner	30	W11286570	Bracket, Grease Tray (Left)	52	W10128776	Shelf, Side (Rt)
11	W10128624	Burner, Rear	31	W10128658	Shelf, Side (Lf)	53	W10128774	Hook
12	W10128625	Bracket, Rear Thermocouple	32	W10128659	Bracket, Handle	54	W10128775	Burner, Main
13	W10128626	Cover, Rear Thermocouple	33	W10128660	Handle, Shelf	55	W10128776	Bracket, Main Brnr
14	W10128627	Orifice, Rear Burner	34	W10128662	Bar, Tool	56	W10128777	Thermometer
15	W10128628	Light, Grill	35	W10128663	Harness, Wire Light	57	W10128779	Bezel, Thermometer
16	W10136418	Light, Grill (Set)	36	W10128664	Cover, Igniter	58	W10128780	Insulator, Thermometer(Small)
17	W10128631	Socket, Light	37	W10128665	Igniter	59	W10128782	Insulator, Thermometer(Large)
18	W10128632	Panel, Access	38	W10128751	Nameplate	60	W10128783	Handle, Hood
19	W10128634	Bracket, Panel Left	39	W10128753	Knob, Main Burner	61	W10128785	Endcap, Handle (Left)
			40	W10128756	Knob, Rear Burner	62	W10128786	Spacer, Handle
			41	W10128759	Bezel, Knob	63	W10128787	Endcap, Handle (Right)
						64	W10128788	Hinge, Lid
						65	W10128789	Hood

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE PARTS

For Models: KFRS361TSS00
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10128666	Ring, Rubber
2	W10128667	Box, Transformer
3	W10128668	Cover, Transformr Box
4	W10128669	Transformer
5	W10128670	Clamp, Wire
6	W10136421	Panel, Rear
7	W10128672	Caster
8	W10136424	Panel, Bottom
9	W10128674	Bracket, Tank Tray (Right)
10	W10128675	Bracket, Tank Tray (Left)
11	W10128676	Slide, Tank Tray
12	W10128677	Bolt, Tank

Illus. No.	Part No.	DESCRIPTION
13	W10128678	Tray, Tank
14	W10128679	Lock, Tank Tray
15	W10128680	Handle, Tank Tray
16	W10128681	Bracket, Towel Rack
17	W10128686	Rack, Towel
18	W10136429	Tray, Condiment
19	W10136430	Door, Left
20	W10128696	Hole Plug
21	W10128697	Magnet, Door
22	W10136431	Door, Right
23	W10128703	Bag, Lighting Rod
24	W10128704	Rod, Lighting
25	W10128705	Caster, W/Brake
26	W10136432	Panel, Side Assy

Illus. No.	Part No.	DESCRIPTION
27	W10128711	Cover, Battery Box
28	W10128715	Box, Battery
29	W10128719	Case, Battery Box
30	W10128746	Regulator
31	W10128747	Fixture, Manifold
32	W10128748	Connector (Brass)
33	W10128749	Base, Manifold Fixture
34	W10128750	Commutator, Manifold
35	W10128661	Handle, Door
36	W10128659	Bracket, Handle
37	W10136427	Rack, Storage

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KFRS361TSS00

(Stainless Steel)

Illus.	Part	
No.	No.	DESCRIPTION

Miscellaneous

4396540	Altitude 2K-5K LP
4396541	Altitude 5K-8K LP
4396542	Altitude 8K-10K LP
4396544	Altitude 2K-5K NG
4396545	Altitude 5K-8K NG
4396546	Altitude 8K-10K NG
W10118099	Conv.Kit (NG-LP)
W10118098	Conv.Kit(LP-NG)
	Smoker Box
KFKU361TSS	36" Rotiss. Kit