Santos 3004 Santos 3004



bodum

Welcome to BODUM®

We congratulate you on your purchase of the SANTOS 3004 coffee maker. With this machine you will be able to make aromatic coffee.

OPERATING PRINCIPLE

The water is heated in the jug. The steam generated forces the water through the riser tube and into the funnel. The gentle heating of the ground coffee enhances the coffee's beneficial qualities. The coffee is brewed at the ideal temperature and develops its full aroma. Once the correct brewing time has elapsed, the heating element switches off and the coffee flows back into the jug - it is now ready to serve.

The Santos coffee maker 3004 allows you to prepare between 3 cups (0.375 I/12.5 oz) and 6 cups (0.75 I/25 oz) of coffee. The cycle time can vary according to the amount of water, the amount of coffee and the grind of coffee, for 6 cups (0.75 I/25 oz) it takes approximately 5 minutes.

After 15 minutes the machine switches off automatically.

Intended use. The "Santos" coffee maker is designed only for brewing coffee with ground coffee beans. Coarse or finely ground coffee may be used. BODUM® recommends using a grind suitable for filter coffee. Instant coffee is not suitable.

Warning! Never use the unit to boil water! Never heat up cold, brewed coffee.

The coffee maker is intended exclusively for household use and may therefore be operated only in the household.



1 Funnel cover 2 Filter 3 Funnel 4 Seal 5 Swing 6 Lid of jug

7 Jug

- 8 Level indicator with MIN and MAX filling marks
- 9 Power base
- 10 Cable storage 11 ON/OFF switch
- unit on a dry,
- Always allow the unit to cool down before cleaning.

bodum

SAFETY INSTRUCTIONS

Damaged

be taken

BODUM[®]

BODUM[®]

dealer for

repairs.

units should

immediately

to the nearest

HOME STORE

or authorized

WHAT TO DO:

Use the unit

exclusively in

and only for

the intended

purpose (see

"Intended

use").

the household

If the supply Only operate cord is damthe unit with aged, it must the rated voltbe replaced age indicated by the manu-(see label on facturer or its base of unit). service agent or a similarly

qualified

person in

a hazard.

order to avoid

SAFETY INSTRUCTIONS



Switch off the unit before removing the plug from the electrical outlet. Always pull only on the plug and never on the







Always place the



SAFETY INSTRUCTIONS WHAT YOU MUST NOT DO:

Do not allow children to operate the unit without supervision. Children do not recognize hazards.

NSTRUCTIONS

SAFETY I

The power base and parts of the jug become very hot during operation! Lift the jug only by the handle; do not touch hot surfaces!

Under no circumstances should you operate units in which parts are defective or missing.

Do not crush the cable or lead it around corners or sharp edges! Store excess cable in the base of the unit.

COFFEE PREPARATION

Before first use.

Every unit is tested and carefully packed before shipping. Nevertheless, please check before use that the unit is complete and is not damaged anywhere.

Before the first brewing.

Flush the unit without coffee. To do this, fill the jug with water, boil and pour out. Always make sure that the jug is filled with enough water for brewing coffee. The MIN mark on the level indicator must always be reached, i.e. always fill with at least enough water for 3 cups (0.375 I/12.5 oz).



Operate the unit

inal parts only.

any liability or

guarantee if the

unit is fitted with

any other parts.

with BODUM® orig-

BODUM[®] declines



Do not place the

unit or parts near

a stove or oven or

in a microwave

oven





1. Pull the cable out of the power base for at least 2/3 of its length.

2. Plug in the cable, leading



3. Fill the jug with the desired amount of cold water.







Never open the

Have repairs

by authorized

experts.

performed only

power base or the

bottom of the jug!



4. The MIN mark on the level indicator must be reached!



5. Place the jug on the power base



6. Turn the funnel around on its axis to fit it on the jug. Note: Wetting the seal facilitates fitting of the funnel.







To protect against

shock or injuries,

the cable, plug or

them to come into

never immerse

power base in

liquids or allow

contact with

liquids.

fire, electric





7. Ensure that the funnel sits securely on the jug and that the seal is evenly compressed.



8. Place the filter in the funnel.



9. Ensure that the filter snaps audibly in position!

it as directly as possible.



10. Place the desired amount of ground coffee in the funnel. We recommend one BODUM[®] scoop (7g/0.25 oz) per BODUM[®] coffee cup (1.25 dl/4 oz).



13. As soon as there is no water left in the funnel, the coffee is ready.



11. Place the cover on the funnel.



14. A funnel holder is integrated in the power base. Press lightly on the swing.



12. Press the switch marked "ON" at the side of the machine. The switch will light up to show that the machine is switched on. Caution: The unit will become hot and steam may escape from the openings in the cover.



15. Turn the swing outwards from the power base.

CLEANING



Remove the cover from the funnel and discard the coffee grounds.




Remove the filter from the funnel. Rinse and clean the funnel and filter with water. Both parts are dishwasher safe.

Clean the jug with warm water and washing-up liquid.

Warning: Do not immerse the jug in liquids. Do not clean the jug under running water.







16. Hold the jug firmly by the handle and tip the funnel aside slightly. Warning: Hot parts! Lift the jug only by the handle.



17. Place the funnel on the funnel holder on the power base, or else in the sink.



18. The coffee can now be enjoyed.



Warning: Unplug the power base before cleaning and do not immerse in liquids or clean under running water.

Replace the cable in the storage area in the base.



The filter has to be changed as soon as the mesh has any defects, or at least once every three months. Filter plates are available at any BODUM[®] HOME STORE or authorized BODUM[®] dealer. Loosen the screw in the filter and replace the filter plate.

Warning! Allow all parts to cool before cleaning! The plastics selected by BODUM* are perfectly suited for coffee machines. Use only water and mild detergents for cleaning and no scouring or aggressive cleaning agents. Warning! The power base and the jug may never be placed in the dishwasher or immersed in liquids! Parts marked with the symbol



can be cleaned in the dishwasher.

SERVICE & GUARANTEE

9

LIME REMOVAL



Coffee has a slightly descaling effect. If lime deposits are only slight, it is sufficient to leave a little coffee in the jug after each brewing cycle over a period of 2-3 days.

To descale we recommend the use of ordinary commercial descalers. For the regular removal of scale and discolouring from the jug we recommend using BODUM® cleaner and descaler.



1. Dissolve contents of BODUM® cleaner and descaler package in 4 cups warm water.



2. Turn machine on and begin the brew cycle.



3. Rinse all components and repeat steps 1 and 2 twice with clean water.

SERVICE & GUARANTEE CONDITIONS

All BODUM[®] products are made of high-guality, durable materials. However, should parts require replacement, please contact one of the following:

your BODUM® dealer - the BODUM® HOME STORE - the BODUM® representative in your country, or our home page at www.bodum.com

Guarantee. BODUM® guarantees the "Santos" coffee maker for 2 years from date of purchase against material defects or malfunctions which can be traced back to defects in manufacturing or design.

Repair is free of charge provided all guarantee requirements are fulfilled.

Guarantee requirements. The guarantee certificate must be completely filled out by the seller at the time of purchase. Only agents authorized by BODUM® may perform guarantee services.

BODUM® makes no guarantee for damage which can be attributed to use for unintended purposes, incorrect handling, normal wear and tear, defective or incorrect maintenance or service work, incorrect operation or manipulation by unauthorized persons.

> **TECHNICAL DATA:** Mains voltage: 230V 50Hz or 120V 60Hz Rated power: 1200W Cable length extendible to 80cm Net contents: 0.375 - 0.75 litres 12.5 - 25 ounces