

# **Undercounter Dishwasher**

### PRODUCT MODEL NUMBERS


 MDB4709AW
 MDBH949AW

 MDB6709AW
 MDBH969AW

 MDB6769AW
 MDBTT53AW

## **DRAIN REQUIREMENTS**

- A new drain hose is supplied with your dishwasher. If this is not long enough, use a new drain hose with a maximum length of 12' (3.7 m) (Part Number 3385556) that meets all current AHAM/IAPMO test standards, is resistant to heat and detergent, and fits the 1" (2.5 cm) drain connector of the dishwasher.
- Make sure to connect drain hose to waste tee or disposer inlet above drain trap in house plumbing and 20" (50.8 cm) minimum above the floor. It is recommended that the drain hose either be looped up and securely fastened to the underside of the counter, or be connected to an air gap.



 Make sure to use an air gap if the drain hose is connected to house plumbing lower than 20" (50.8 cm) above subfloor or floor.

# WATER SUPPLY REQUIREMENTS

• A hot water line with 20-120 psi (138-862 kPa) water pressure can be verified by a licensed plumber.

#### **ELECTRICAL REQUIREMENTS**

You must have:


- 120-volt, 60 Hz, AC-only, 15- or 20- amp., fused electrical supply.
- · copper wire only.


We recommend:


- · a time-delay fuse or circuit breaker.
- a separate circuit.

If connecting dishwasher with a power supply cord:


- Use UL Listed power supply cord kit (Part Number 4317824) marked for use with dishwasher.
- Power supply cord must plug into a grounded 3 prong outlet, located in the cabinet next to the dishwasher opening. Outlet must meet all local codes and ordinances.







### PRODUCT DIMENSIONS



Corner locations require a 2" (5.1 cm) minimum clearance between the side of the dishwasher door and the wall or cabinet.

