

Cisco SFS Multifabric Server Switch Shelf & Rack Ear Kit Installation Guide (Topspin 360)

Part Number: OL-7733-01 Product ID: 140273 Copyright © 2004 - 2005 Topspin Communications, Inc. All rights reserved.

The Topspin Switched Computing System, Topspin Host Channel Adapter, Topspin Element Manager, and collateral software programs and documentation are subject to and made available only pursuant to the license agreement signed by you and Topspin, Communications, Inc. (or if no signed license agreement exists, the license agreement included with your original media) and may only be used in accordance with the terms of that agreement. Making copies, modifications, or compilation works of the software except as specifically allowed in that agreement is prohibited by law and constitutes a punishable violation of the law. This documentation may not be copied, modified or reduced to any electronic or machine-readable form without Topspin Communication, Inc.'s prior written consent.

As defined in FAR section 2.101, DFAR section 252.227-7014(a)(1) and DFAR section 252.227-7014(a)(5) or otherwise, the collateral software programs provided to you are "commercial items," "commercial computer software" and/or "commercial computer software documentation." Consistent with DFAR section 227.7202, FAR section 12.212 and other sections, any use, modification, reproduction, release, performance, display, disclosure or distribution thereof by or for the U.S. Government shall be governed solely by the terms of the license agreement and shall be prohibited except to the extent expressly permitted by the terms of that agreement. Any technical data provided that is not covered by the above provisions shall be deemed "technical data-commercial items" pursuant to DFAR section 227.7015(a) or equivalent. Any use, modification, reproduction, release, performance, display or disclosure of such technical data shall be governed by the terms of DFAR section 227.7015(b) or equivalent.

This documentation may include technical inaccuracies or typographical errors and is subject to correction and other revision without notice. TOPSPIN PROVIDES THIS DOCUMENTATION "AS IS" AND WITHOUT ANY WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states or jurisdictions do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

© Copyright 2004 - 2005, Topspin Communications, Inc. All rights reserved. Topspin is a registered trademark and the Topspin logo, TopspinOS, and Topspin Switched Computing System are trademarks of Topspin Communications, Inc. Other company, product, or service names are the property of their respective owners.

Document Version: 2.2.0 Update 1

Part Number: OL-7733-01

Product ID: 140273

March, 2005

Printed in the United States of America.

Topspin Shelf and Rack Ear Kit Contents

The following contents are included in this package:
Topspin Shelf and Rack Ear Kit for Topspin 360 Contents and Installation Guide(1)
Shelf (1)
Rack Ears (2)
Flat Countersink Screws (8)
Panhead Screws (4)
To register your products with Topspin customer support, or to locate more detailed hardware information:
http://www.topspin.com/support/

Rack the Topspin 360 with the Optional Topspin Shelf and Rack Ear Kit

The Topspin 360 can be installed using your own rack shelf. Refer to the *Topspin 360 Hardware Guide* for instructions on racking the server switch without the optional Topspin shelf.

This document describes the installation of the Topspin 360 server switches if you have purchased the optional shelf kit.

Requirements

In addition to the accessories provided with the server switch, you need:

- #2 phillips screwdriver
- Rack with the appropriate amount of available space:
 - 5 Us for the Topspin 360

Install the Rack Ears

- 1. Determine the end of the Server Switch to position at the front of the rack.
- 2. Install the rack ears using the screws provided.



Figure 2-1: Install the Rack Ears on the Chassis

Install the Shelf Kit

Separate the sliding piece from the main shelf unit.
Note the way that the pieces fit together. The flanges face outward.
The right bracket is engraved with an EXR, and the left bracket is engraved with an EXL.



Figure 2-2: Separate the Sliding Bracket From Both Sides of the Shelf Unit

2. Attach the wide bracket pieces to the rear rack posts (opposite from the side with which you want to align the switch).

The right bracket is engraved with an EXR, and the left bracket is engraved with an EXL.

- a. Set one of the wide bracket pieces against the inside of the rack. The flange of the bracket faces outward, and wraps around to rest against the outside of the rear rack post.
- b. Align the holes of the bracket piece with the holes of the rack post. This varies slightly depending on your rack; however, in most cases, the bottom of the bracket should be aligned with the 1U hash mark.

The switch and shelf will take up 5Us for the Topspin 360 or 6Us.




Figure 2-3: Align Bracket with Rear Post

- c. Screw the brackets to the rack, using screws that fit your rack.
- d. Repeat with the second bracket on the second rear rack post. Be careful to install both brackets evenly with each other, as the switch will not be able to be installed if the shelf is not even.




Figure 2-4: Attach Brackets to Post Separate from Shelf Unit

3. Align the back end of the shelf with the exposed ends of the mounted brackets in the rack. The back of the shelf unit is the straight end (opposite the end with flanges). There are channels inside the shelf into which the brackets slide.




Figure 2-5: Align Shelf with Installed Brackets

4. Push the shelf into the rack until the front flanges of the shelf meets the rack posts.




Figure 2-6: Push Shelf Unit into Rack

- 5. Screw the bracket and shelf together from the inside (required). The number of screws that you use on each side will depend on the size of your rack.
 - a. Depending on the amount collapse or extension required of the shelf to fit your rack, use either two screws (minimum) or four screws (maximum).




Figure 2-7: Screw the Bracket Into the Shelf From Inside the Rack

- 6. Attach the front of the shelf to the rack posts, using screws that fit your rack.
 - a. (Optional) You may want to wait to completely tighten screws until you have placed the switch in the rack. This will allow you to make slight adjustments.



Figure 2-8: Screw the Shelf Ears to the Rack Posts

7. Verify that the shelf has been installed evenly.

Lift the Chassis onto the Shelf

- 8. Place the switch in the rack.
 - a. Lift the switch (using at least two people). Face the side of the chassis without handles toward the rack.
 - b. Rest the end of the chassis at the edge of the shelf. Push the chassis back into the rack until the handles meet the rack posts. Make sure that the left and right sides of the chassis are pushed back evenly.

NOTE: There are no side rails for the current Topspin 360 chassis.

Secure the Chassis

- 9. Attach the chassis handles to the rack posts, using screws that fit your rack.
- 10. Tighten any screws that you left loose for adjustment.