



# CABINET PARTS

For Models: KUWO24RSBX01


(Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	13	4344771	Bracket, Grille	27	4344792	Thermal Fuse
	2300273	Use & Care Guide	14	4344840	Evaporator Fan	28	4344793	Screw
	4344900	Wiring Diagram			Assembly	29	4344791	Screw
2		Cabinet (Not A	15	4344859	Thermostat	30	4344783	Fan Blade
		Service Part)	16	4344768	Knob, Thermostat	31	4344878	Screw
3	4344739	Lens, Light	17	4344767	Switch, Plunger	32	4344865	Evaporator Fan
4	4344740	Bulb, Light	18	4344826	Screw			Motor
5	4344746	Heater, Defrost	19	4344797	Screw	33	4344877	Harness, Wire
6	4344747	Heat Shield	20	4344819	Clip, Grille	34	4344832	Screw, Ground
7	4344761	Grille	21	4344825	Screw	35	4344778	Grommet, Fan Motor
8	4344762	Plate, Bottom	22	4344823	Seal	36	4344899	Bracket, Motor
9	4344763	Foot, Leveling	23		Frame, Support	37		Evaporator
10	4344764	Brace, Support		4344821	Right			(Not Serviced)
11	4344898	Control Box		4344820	Left	38	4344858	Switch, Light
12		Frame, Side	24	4344824	Clip, Harness	39	4344917	Transformer Cable
	4344769	Left Side	25	4344857	Harness, Wire			
	4344770	Right Side	26	4344827	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# SHELF PARTS

For Models: KUWO24RSBX01  
(Black)



Illus. No.	Part No.	DESCRIPTION
1	4344879	Temperature Separator
2	4344844	Wine Rack, (4)
3	4344845	Wine Rack, (1)
4	4344848	Wine Rack, Lower
5	4344842	Left Side
	4344843	Right Side
6	4344794	Screw


Illus. No.	Part No.	DESCRIPTION
7	4344795	Washer
8	4344850	Stop, Lower Rack
9	4344851	Screw
10	4344882	Trim, Top And Middle Racks
11		Support
	4344866	Left
	4344867	Right
12	W10163279	Trim, Lower Rack

Illus. No.	Part No.	DESCRIPTION
13		Support, Bumper
	4344885	Left
	4344886	Right
14		Screw
	4344914	Left
	4344915	Right
15	4344895	Transformer Cable
16	4344894	PCB Display Board
17	W10162986	Screw-W/Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KUWO24RSBX01  
(Black)



Illus. No.	Part No.	DESCRIPTION
1	4344890	Door Assembly (Includes Gasket)
2	W10162992	Washer/Bottom
3	W10163191	Gasket-Push Plate
4	4344753	Hinge, Bottom
5	4344754	Hinge, Top
6	4344804	Spacer, Top Hinge
7	4344798	Spacer, Bottom Hinge
8	4344757	Actuator, Switch


Illus. No.	Part No.	DESCRIPTION
9	W10163283	Door Stop
10	4344852	Door Gasket
13	4344760	Washer
14	4344803	Spacer, Door
16	4344796	Screw
17	4344906	Screw, Lower Hinge
	4344906	Quantity 1
	4344797	Quantity 3
18	4344827	Screw

Illus. No.	Part No.	DESCRIPTION
19	4344800	Screw
20	4344801	Screw
<b>OPTIONAL PARTS NOT ILLUSTRATED</b>		
	4344818	Installation Kit, Door Panel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: KUWO24RSBX01  
(Black)



Illus. No.	Part No.	DESCRIPTION
1	W10163193	Drain Pan
2	4344773	Bracket, Defrost Timer
3	4344774	Defrost Timer
4	4344797	Screw
5	4344776	Start Device
6	W10175971	Mounting Plate, Compressor
7	4344778	Grommet, Fan Motor
8	4344779	Grommet, Compressor
9	4344780	Bolt, Compressor
10	4344781	Fan Motor, Condenser
11	4344782	Baffle, Air
12	4344783	Fan Blade
13	4344784	Bracket, Motor

Illus. No.	Part No.	DESCRIPTION
14	4344785	Bracket, Motor
15	4344786	Cover, Rear
16	4344837	Capacitor
17	4344836	Clip
18	W10163276	Trap, Drain
19	4344861	Power Cord
20	4344829	Cable Tie
21	W10163273	Drier
22	4344838	Bushing
23	4344831	Clip, Bushing
24	W10163274	Pad-Rubber
25	4344826	Screw
26	4344825	Screw
27	4344832	Screw
28	4344775	Compressor (Includes Items 5, 8, 16, 17 & 21)

Illus. No.	Part No.	DESCRIPTION
29	4344834	Screw
30	4344833	Screw
31	4344862	Transformer
32	W10163278	Thermostat
33	4344864	Bracket, Thermostat
34	4344881	Ballast
35	4344907	Trim, Edge
36	4344908	Support, Drain

**REFRIGERANT CHARGE**

3.5 Ounces  
(R-134A)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST