


# Stainless Steel Canister Vacuum Item # XDB242H for Model CV242H 10 HEPA Paper Bags


Warning: To reduce the risk of electric shock, the power cord must be disconnected before changing the HEPA bag or performing maintenance/trouble shooting checks.


#### Changing the HEPA Bag:

- 1. To open the dust bag cover, remove the flexible hose and depress the dust bag cover release button. (Fig. 1)
- 2. Lift dust bag cover up by handle.
- 3. Holding the HEPA dust bag in your hand with the arrow pointing down, slide it firmly between the slots in the bag holder. (Fig 2)
- 4. Ensure that the cardboard face of bag rests securely in place. You will see the lever lock into place. (Fig. 3)
- 5. Replace dust bag cover. (Fig. 4)

**Note:** Always remove the power plug from the wall outlet before assembling or removing accessories.







**Caution:** Make sure that the cardboard section of the dust bag is firmly in place inside the dust bag support.

**Caution:** The dust bag compartment will not close if the dust bag is not inserted properly into the unit. Never use the vacuum without a dust bag inserted into the unit. **NEVER** reuse the paper dust bags.



### **NEVER REUSE HEPA BAGS**

**Fantom**94 Main Mill Street, Door 16
Plattsburgh, NY 12901
Tel.:1 (800) 275-9251

Rev. 03/05 Printed in China

## FANTOM®


# Stainless Steel Canister Vacuum Item # XDB242H for Model CV242H 10 HEPA Paper Bags


Warning: To reduce the risk of electric shock, the power cord must be disconnected before changing the HEPA bag or performing maintenance/trouble shooting checks.

### Changing the HEPA Bag:

- 1. To open the dust bag cover, remove the flexible hose and depress the dust bag cover release button. (Fig. 1)
- 2. Lift dust bag cover up by handle.
- 3. Holding the HEPA dust bag in your hand with the arrow pointing down, slide it firmly between the slots in the bag holder. (Fig 2)
- 4. Ensure that the cardboard face of bag rests securely in place. You will see the lever lock into place. (Fig. 3)
- 5. Replace dust bag cover. (Fig. 4)


**Note:** Always remove the power plug from the wall outlet before assembling or removing accessories.





**Caution:** Make sure that the cardboard section of the dust bag is firmly in place inside the dust bag support.

**Caution:** The dust bag compartment will not close if the dust bag is not inserted properly into the unit. Never use the vacuum without a dust bag inserted into the unit. **NEVER** reuse the paper dust bags.



## **NEVER REUSE HEPA BAGS**

Fantom 94 Main Mill Street, Door 16 Plattsburgh, NY 12901 Tel. :1 (800) 275-9251

Rev. 03/05 Printed in China