

Ages: 5+ Players: 2-6

Contents: 1 Hot Potato, 2 AA batteries (included) and 13 potato chip cards

Game Play: Don't be the player holding the Hot Potato when the music stops!

- Open the velcro pocket and ensure the switch is in the "on" position.
- Players can stand or sit in a circle.
- Squeeze the potato to start the music.
- Toss or pass the potato to another player. It doesn't matter if the player is next to you or across the room!
- The last player to touch the potato when the music stops takes a potato chip.
- If the music stops while the potato is in mid-air, the last player to touch the potato takes a chip.
- Squeeze the potato and start a new round.
- Players who collect 3 chips are out of the game!
- The last player in the game wins!


When storing the Hot Potato, open the Velcro pocket and flip the switch to the "off" position.

Battery Replacement:

• Hold open the Velcro pocket on the potato's back.



• Remove this screw with a Phillip's screwdriver.



- Open the lid and exchange 2 AA batteries in the polarity shown.
- Replace the lid and secure the screw.
- Close the pocket.

BATTERY SAFETY INFORMATION

- Never mix old and new batteries (replace all batteries at the same time).
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always replace all batteries at the same time.
 Alkaline batteries are recommended for best performance.
 Rechargeable batteries are to be removed.
- from the toy/game before being recharged.
 Rechargeable batteries are only to be recharged under adult supervision.
- Non-rechargeable batteries are not to be
- recharged.

 Do not mix different types of batteries
- . Only batteries of the same or equivalent
- type as recommended are to be used.

 Batteries are to be inserted with correct polarity.

 Exhausted batteries are to be removed from
- Supply terminals are not to be short-circuited.
 Dispose of batteries safely (Do not dispose of batteries in fire, batteries may explode or leak).



©2006 Fundex Games, Ltd. P.O. Box 421309 • Indianapolis, IN 46242 MADE IN CHINA

Questions or comments? Write to us at the address above, call 1.800.486.9787 or email customerservice@fundexgames.com www.fundexgames.com

In an effort to continually improve our products, items may vary from those shown. Item # 2561-00-13