# SAMSUNG MULTI - CLIP MANUAL

## 1.OPERATING WITH SAMSUNG MULTI-CLIP

Insert clip to the phone.

Cell should be switched on or swithed off (it depends on phone model). In most cases it should be switched off.

Clip is power supplied from the phone, but there is no problem to use 9v battery power supply (construction of the clip allows that).

After choosing adequate model press "unlock" button.

## REPAIR OPTION

THIS OPTION IS AVAILABLE TO MODELS: A200/T100-T700/R200-R225/N100-N620

ALL YOU NEED TO DO IS PRESS "REPAIR" BUTTON. THERE'S NO NEED TO CHOOSE MODEL OF THE PHONE.

## 1. FUNCTION OF THE BUTTONS.



# 2. CHOOSING MODEL

Press button "choose model" several times. Observe following situations.



If no diode is shining, You choose models:

Q100,Q105,Q108,Q200,Q205 Q208,Q300,Q305,Q308



If diode nr1 ( orange) is shining, You choose models:

V100,V200,V205,V208 S100-S300



If diode nr2 ( green) is shining, You choose model:

A800



If diode nr3 ( yellow) is shining, You choose models:

A100, A300, A400, M100



If diode nr4 ( red ) is shining, You choose models:

A200 T100-T700 R200-R225 N100-N620



If all diodes are shining, You choose model C100