

Excalibur Electronics

Micro Forever Flashlight



Model H423 Model H423B Model H423G Model H423Y ongratulations on your purchase of Excalibur Electronics' Micro Forever Flashlight, the flashlight that *never* lets you down. At home, in the car, in your camper or boat or storm emergency kit, Micro Forever Flashlight is always ready, even if you haven't used or checked it for years!

Features


- Rechargeable capacitor
- Super-bright LED visible for over a mile
- · Zero maintenance required
- · Floats on water
- · Water and weatherproof

Charging the Micro Forever Flashlight


Your Micro Forever Flashlight never needs a battery. It is charged by shaking the unit. For best results, follow these steps in charging:

- 1. Turn the unit off. (See figure below, right.)
- 2. Hold the unit parallel to the ground and shake it with moderate force about two to three times per second. (See diagram at top of next page.)

NOTE: Shaking the unit too hard may cause damage. Shaking vertically won't charge the unit efficiently.



Micro Forever Flashlight will provide you with five to seven minutes of light when charged for 30 seconds. If the unit is completely drained of energy, you should give the unit 90 shakes—or about 30 seconds of shaking at 3 shakes per second—to fully charge its capacitor.



Cautions

Micro Forever Flashlight generates a strong magnetic field that surrounds it. Keep the unit at least one foot away from medical devices, computers, magnetic storage media, or other devices such as:

Pacemakers

· Credit cards

• Cassette tapes

- Televisions
- Computer disks

- Any device with a cathode ray
- Video tapes tube (CRT)

Do NOT attempt to remove the Light Emitting Diode (LED) or any internal part.

Special Care & Safety

- · Avoid rough handling such as bumping or dropping.
- · Use only warm water and mild soap to clean the housing.
- · Rinse with fresh water.
- · Clean the lens with glass-cleaning products.
- Do not use petroleum distillates (such as gasoline or kerosene) or solvents such as acetone to clean any part of the Micro Forever Flashlight.

LIMITED ONE-YEAR WARRANTY

EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of ONE YEAR from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address shown at right.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of the top panel voids all warranties. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to ONE YEAR from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do

not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply.

The only authorized service center in the United States is:

Excalibur Electronics, Inc. 13755 SW 119th Ave Miami, Florida 33186 U.S.A.

> Phone: 305.477.8080 Fax: 305.477.9516

www.ExcaliburElectronics.com

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton.

If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING. WE CANNOT STORE YOUR UNIT!