

Model Quatech USBN-500NAS

2-Port USB 2.0 Device and
2-Port NAS Device Server over IP

Quick Installation Guide

- The default IP of this USB device server is 192.168.3.22:901
- If you need to change IP of this device server, please set up your PC as 192.168.3.XXX where XXX is a different number from 22.
- After set up your PC IP, then open a web page, and type <http://192.168.3.22:901> to reach the Logon page. Username is “root”, and password is “combo”.
- For more detailed setup & functions of this device server, please refer to User’s Manual.