



AC 706 AM



AIR COOLER & HEATER

GB Air cooler & heater

www.amcorgroup.com

THANK YOU

Thank you for choosing this innovative Amcor air cooler & heater. We suggest that you keep this manual in a safe place for future reference. It describes the many benefits and advanced features this unique product has to offer. Before you use your AC 706 AM you should carefully read these instructions to maximise this product's performance.

For over 50 years Amcor has specialised in complete indoor environmental control, manufacturing and marketing; dehumidifiers, portable air conditioners, coolers, air purifiers, ionisers and aroma therapy scent diffusers. These world class products incorporate the latest technological developments.


SAFETY INSTRUCTIONS

IMPORTANT!

- The unit is designed for indoor operation.
- Rating: This unit must be connected to a 220-240 V / 50 Hz earthed outlet.
- The installation must be in accordance with regulations of the country where the unit is used.

If you are in any doubt about the electrical installation, have it checked and if necessary modified by a qualified electrician.

- The AC 706 AM is safe. However, as with other electrical appliances, use it with care.
- Keep out of the reach of children.
- Do not clean the unit by spraying it or immersing it in water.
- Do not insert any object into the opening of the unit.
- Disconnect it from the mains before cleaning the unit or any of its components.
- Never connect the unit to an electrical outlet using an extension cord. If an outlet is not available, one should be installed by a licensed electrician.
- Don't lift or move by pushing the unit at the rear, but always at the side.



WARNING

- Never operate this appliance if it has a damaged cord or plug. Do not lead the cord over sharp edges.
- A damaged supply cord should be replaced by the manufacturer, its service agent or a qualified person in order to avoid a hazard.
- Any service other than regular cleaning or filter replacement should be performed by an authorized service representative. Failure to do so could result in a loss of warranty.


Do not use your AC 706 AM under the following conditions:



If the power cable wires are frayed or cut



When small children may be left unattended




On a slope or uneven surface




Close to a naked flame



This product is not made for DIY repair




If there is a risk of liquid falling on the unit




Inside unit exposed to the weather outdoors



Near water




If an extension lead may become overloaded



Where the power cable may be damaged



Where it may be damaged by chemicals



Where there is a risk of interference by foreign objects




Reminder:


Waste electrical products must not be disposed of with household waste. This product should be taken to your local recycling centre for safe treatment.

PARTS

FRONT




REAR




HOW IT WORKS

EVAPORATIVE COOLING




HEATING



OPERATION

1. Pour clean, cold water through the water hole. Stop the water supply when the indicator reaches the red point.
2. Or store ice cubes into the ice tank, the cool air will be colder and more comfortable than the water you supply.
3. Plug the unit into the correct voltage.
4. Turn the timer switch to ON or adjust the timer to switch OFF in up to 8 hours.
5. Adjust speed switch to the desired cool air. 'H' for high, 'M' for medium, 'L' for low fan speed.
6. Push the cool button ON, the air filter will rotate, a mist of cool air will come out about 3 minutes later. When the cool button is OFF, only dry filtered air will be supplied.
7. Push the swing button ON, the louvres will make a 120° sweep. Or switch the swing button to OFF and choose the desired air direction manually.
8. Move the louvres of the air vent to direct the air higher or lower.




CAUTIONS

- Do not pour water into the ice tank.
- When the product is not in use, make sure the timer switch is left in the 'OFF' position.
- Do not place the unit directly against curtains or walls.
- Moving of the unit should be slow and with the unit positioned sideways. Be careful not to knock the unit over!
- Do not place objects on the unit.
- Do not obstruct the flow of air.
- Wash the filter and water tank every 2 weeks.
- Do not leave/store with water inside.

HOW TO CLEAN THE AIR FILTER AND WATER TANK

1. Unplug and position in an area where water will do no damage.
2. Place a container behind the unit, loosen the knob at the rear low plate and the water will flow from the tank into the container.
3. Unscrew and release the rear plate.
4. Pull out the terminals and take out the air filter together with the rear plate.
5. Clean the air filter. Be careful not to splash the small motor with water. Do not wash the small motor with running water.
6. Replace the air filter, screw back the rear plate and replace the knob.



TECHNICAL DATA

Voltage and frequency		220 - 240 V / 50 Hz
Power cool: hot:	W	75 - 91 860 - 1040 (L) / 1720 - 2090 (H)
Water consumption (at room temperature 28°–33°C and relative humidity 55–60%)	L/h	0.5
Water reservoir capacity		9 litres for upto 18 hours continuous usage at 28°–33°C (55–60% relative humidity)
Ice cubes reservoir	L	4.2
Dimensions (W x D x H)	cm	43.5 x 34 x 64.5
Net weight	kg	10.5

Hong Kong

Amcors Ltd
Suite 2007, Tower 6, The Gateway,
Harbour City, 9 Canton Road,
Tsim Sha Tsui, Kowloon,
Hong Kong
Tel: +852 2997 6865
Fax: +852 2997 6091
Email: amcorhk@amcorgroup.com

United Kingdom

Amcors Ltd
9 Ryan Drive, West Cross Centre,
Great West Road, Brentford,
Middlesex, TW8 9ER,
United Kingdom
Tel: +44 20 8560 4141
Fax: +44 20 8232 8814
Email: amcoruk@amcorgroup.com

USA

Amcors Inc.
685A Gotham Parkway, Carlstadt,
New Jersey 07072,
United States of America
Tel: +1 201 460 8100
Fax: +1 201 460 9481
Email: amcorusa@amcorgroup.com

The Netherlands

Amcors B.V.
Anton Philipsweg 9-11,
1422 AL Uithoorn,
The Netherlands
Tel: +31 297 560 079
Fax: +31 297 523 062
Email: amcorex@amcorgroup.com

Israel

Amcors International Ltd
1 Sapir St.,
P.O. Box 12001
Hertzeliya Pituach,
Israel
Tel: +972 9951 5351
Fax: +972 9958 5650
Email: amcoril@amcorgroup.com

Singapore

Amcors Investments (Singapore) Pte Ltd
545 Orchard Road,
#13-02, Far East Shopping Centre,
Singapore 238882
Tel: +65 6297 9881
Fax: +65 6297 8891
Email: amcorsg@amcorgroup.com

China

Shan Xia Industrial Development Zone,
Heng Li Town, Dongguan City,
Guangdong Province, China

Plant One - Amcor (China) Ltd

Tel: +86 769 8372 1090
Fax: +86 769 8372 1790
Email: amcorcn@amcorgroup.com

Plant Two - Amcor Appliances Ltd

Tel: +86 769 8372 1970
Fax: +86 769 8372 1790
Email: amcorappl@amcorgroup.com

