NHS-1000 Home Entertainment Solution

SONY

CHOOSE A SOURCE – from the menu that appears on the LCD screen and the system will automatically turn on.

CHOOSE ANOTHER SOURCE — and the system will automatically switch on the other components.

ADJUST VOLUME — with the VOLUME UP/DOWN and MUTING buttons.



Quick Start Guide

Main Room – Radio Frequency (RF) Remote Control

WHEN YOU'RE DONE — press the SYSTEM OFF button, then hit the ALL ZONE OFF button on the LCD screen. The entire system will shut down.

CONTROL PLAYBACK -

with the buttons that appear for each source on the LCD screen.


SONY

Quick Start Guide

Remote Room - In-wall Keypad

TURN IT ON - Press the POWER button. The available sources will appear as a menu in the LCD Window.

CHOOSE A SOURCE - Press the button next to the source name to select the source you want. (To watch television in a remote room, please consult the Operating Instructions.)



CONTROL PLAYBACK - with the familiar PLAY, PAUSE, PREVIOUS, NEXT, and STOP buttons.

CHOOSE ANOTHER SOURCE —

and the system will automatically switch on the other components.

WHEN YOU'RE DONE -

press the **POWER** button to turn off the Remote Room.

> See owners manual for additional control while aimed at wall unit.

MULTI ZONE SYSTEM

with the VOLUME

UP/DOWN and MUTING buttons.

Consumer Support:

Hotline: 1-877-619-7669

email: sonynewhome@info.sel.sony.com

Consult operating manual for full details of system. Please see Important Notice regarding the risk of Image Retention on page 2 of the operating manual.

©2004 Sony Electronics Inc. Sony is a registered trademark of Sony.