


Grizzly *Industrial, Inc.*®

10 WATT GUITAR AMPLIFIER MODEL H6021 INSTRUCTION SHEET



COPYRIGHT © MARCH, 2004 BY GRIZZLY INDUSTRIAL, INC.
WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
#6165 PRINTED IN CHINA

MODEL H6021 CONTROLS



- A. **INPUT:** Connect your guitar here, using a shielded instrument cable with a ¼" jack.
- B. **DRIVE SWITCH:** Turns the Drive Channel *ON* and *OFF*.
- C. **MASTER VOLUME:** This knob controls the overall volume of the amplifier.
- D. **2 BAND EQUALIZATION:** The main equalization of the Model H6021 is a classic 2-band passive network.
- E. **HEADPHONE OUTPUT:** For connection to almost any headphone with a ¼" jack.
- F. **POWER SWITCH:** This switch turns the power *ON* and *OFF*.
- G. **POWER LIGHT:** The power light illuminates when the power is *ON*.

Caring For Your Amplifier

- DO NOT remove the grounding prong to fit the plug into a two-pronged outlet!
- To keep the amplifier working properly, DO NOT expose it to rain or moisture.
- DO NOT pull or lift the amplifier by the power cord.
- UNPLUG the amplifier before cleaning, and only clean with a damp cloth (no chemicals).

