Controls
re: This headset may also be used with a mobile phone. For rating instructions, go to www.rocketfishproducts.com and Quick Setup Guide for model RF-EX7.

Го	Do this	Т	·o	Do this
Mute the microphone	Double-press send/end.	Ir	Increase the volume	Swipe upward ( touch pad. You "beep" for each
Jnmute the microphone	Double-press send/end.			
		L		


## Swipe upward (toward the ear) on the touch pad. You will hear a different "beep" for each level change in volume.

# Decrease the volume | Swipe downward (away from the ear) on the outside of the headset.

Do this...

To...

## 4 Maintaining



## Red (flashing)

Recharge time: About two hours

Talk time: Up to eight hours

Standby time: Up to 300 hours

Know the facts

FCC Part 15

this device must accept any interference received, including interference that may cause undesired operation. FCC ID: EMJTRFEX7

Enable or disable the indicator

Check the battery level (method 1)

Check the battery level (method 2)

Erase paired device information

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the

Do this...

Press the power button and send/end together.

Green = Between 1/2 and full charge:

the battery level is low.

Red = Less than 1 hour talk time remaining.

Turn the headset on, then press and release the power button.

Green then red = Between 1 hour talk time remaining and 1/2 charge;

IC: 4251A-HRFEX7 following two conditions: (1) this device may not cause harmful interference, and (2) Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference

Turn the headset off, then press and hold the power button and send/end together for about Connect the charger to reset the headset, then user can power on headset after remove the charger. Canada IC-RSS210 statement

© 2010 BBY Solutions, Inc., All Rights Reserved Distributed by Best Buy Purchasing,

Turn the headset on. If the indicator flashes red and green, or if it beeps every 5 minutes,

that may cause undesired operation of the device.

LLC 7601 Penn Avenue South, Richfield, MN USA 55423-3645

ENGLISH 10-0829

## RF-GPS31126

WITH PURE SPEECH®

Hear and be heard like never before

rocketfish.

**OUICK SETUP GUIDE** 

## What's in the box: Charger (1) Round earbuds (4)

Rocketfish RF-GPS31126 Bluetooth headset (1) USB charging cable (1) Ear loop (1) Quick Setup Guide (1) Fitted earbuds (medium size is pre-attached) (3)

Send/end button

Charging port

1 Lift the charging port cover, then connect the charger. When the indicator changes from red to green, you can disconnect the charger.

1 Power & Pair



- 2 Turn off your PS3 using the rear MAIN POWER switch, leave it off for about 10 seconds, then turn it back on. Press the front power button. Find the Settings menu then press the  $(\times)$  button on the controller. Highlight the **Register Bluetooth® Device** icon, then press (×). Highlight the **Manage Bluetooth Devices** icon, then press (×). Select **Yes** to register a new device (if this is the first time registering a Bluetooth device), then highlight **Start** 
  - Press and hold the headset's power button for three seconds to turn it on. It automatically enters pairing mode when you turn it on for **2 Get the perfect fit** the first time. While in pairing mode, the headset's LED flashes green, and the PS3 finds and recognizes all Bluetooth devices within its range. Your headset is recognized as **RF-GPS31126**.
  - When prompted for a pass key, enter "0000" (four zeros), then

**Scanning** and press  $(\times)$ .

Use one of the fitted earbuds for the most convenient and mfortable fit, or use a round earbud in combination with the ear loop. To use a rounded earbud:


- Remove the fitted earbud that's already attached, then press the
- round earbud onto the headset.
- 2 Attach the ear loop for a secure fit.



- 1 Attach the appropriate size of fitted earbud onto the headset. The medium fitted earbud is already attached.
- 2 Insert the headset vertically in your ear (shown in Step 2).

To use a fitted earbud:

**3** Rotate the headset up towards your mouth. The flexible portion of the earbud should fit securely towards the back of your outer ear. You may need to guide it to a comfortable position with your finger.



What is PureSpeech®? PureSpeech is a state-of-the-art noise cancelation and signal processing technology created by SRS Labs and CSR. Your RF-GPS31126 headset incorporates PureSpeech so that you can hear your calls in amazing clarity, but also so you can be heard clearly by your callers. PureSpeech is always activated on the RF-GPS31126 so you will hear and be heard like never before.

### highlight **OK** and press (×). The "Register completed" message appears. You will then be taken to a new screen stating *Register* completed. Press (O), highlight Audio Device Settings, then press (×). Within *Input Device*, highlight **RF-GPS31126**, press (×), then set your headset. Then set your microphone input levels to the desired settings (we suggest level 3). The headset is now connected. **To turn off the headset**, press and hold the power button for about two seconds.