


KitchenAid®

OVEN PARTS

For Model: KEBI141YBL4, KEBI141YWH4
(BLACK) (WHITE)

IMPERIAL
24" BUILT-IN ELECTRIC
Self Clean Oven



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: KEBI141YBL4, KEBI141YWH4
(BLACK) (WHITE)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
2 3177545 Bracket, Conduit 3185647 Screw	16 3179848 Clip, Oven Seal	31 4173553 Switch, Door
3 3177626 Cabinet, Back 3185647 Screw	17 3177681 Bracket, Switch	4159117 Nut (2)
6 3178141 Cabinet, Top 3185647 Screw	18 3177923 Insulator, Switch	313489 Screw (2)
7 3183747 Top, Module 3185647 Screw	19 3177622 Bottom, Modulal	33 3179587 Retainer, Seal
8 3177442 Side, Cabinet (R.H. & L.H.) 3185647 Screw	20 3179220 Rail, Support (2) 3185647 Screw	34 3177788 Black Model
9 3181699 Tube, Vent 3185648 Screw (3)	22 3177434 Support, Oven 3185647 Screw	3177786 White Model
10 3150505 Oven Light Assy.	23 3178612 Shield, Radiation 3179795 Screw (6)	3180022 Screw (4)
11 3184533 Gasket, Light	3185647 Screw	4168863 Screw (2)
12 311255 Bulb, Oven Light	24 3177433 Bracket, Hinge 3185647 Screw	35 3183791 Tube, Vent
14 3185863 Frame, Front	3185647 Screw	39 4168203 Cover, Cap Tube
15 3179814 Seal, Door	26 3177559 Back, Module 3185647 Screw	4159445 Screw
	27 3185561 Liner, Oven	40 3177552 Bottom, Oven
	28 3178298 Hinge, Door	41 3182584 Bracket, Control Panel
	29 3182814 Button, Plug	3177991 Screw (4)
	30 3185085 Button, Plug	
		FOLLOWING PARTS NOT ILLUSTRATED
		INSULATION
		3185550 Insulation, Wrap
		3177870 Insulation, Back


OPTIONAL PARTS (NOT INCLUDED)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<u>SPLICING WIRES--25FT. LENGTH</u>	<u>PAINT, TOUCH-UP (1/2oz.)</u>	<u>PAINT, BULK (1 qt.)</u>
350806 18 Ga. 80°c Rating Yellow	72017 White	799344 White
242829 16 Ga. 80°c Rating Blue	72107 Almond	978883 Almond
242820 14 Ga. 150°c Rating Black	72110 Harvest Gold	261891 Harvest Gold
242821 Blue	72112 Toast	285367 Toast
242822 Brown	72113 Platinum	285368 Platinum
242823 Green	72032 Black	
242824 Orange	261869 Citrine White	<u>ADHESIVE</u>
242825 Red		482338 Sealer, Silastic (3 Oz.)
242826 White	<u>PAINT, PRESSURIZED SPRAY (13 oz.)</u>	591014 Adhesive, Loctite (1/3 Oz.)
242827 Yellow	350930 White	
242830 14 Ga. 200°c Rating Brown	350956 Almond	<u>ACCESSORY PARTS</u>
242831 Red	261890 Harvest Gold	799832 Kit, Porcelain Repair (White)
242832 Yellow	285365 Toast	832985 Rack, Cooking (Bi-Level)
242828 12 Ga. 150°c Rating Black	285366 Platinum	
242829 Red	830864 Black	
	350942 Primer	
	350941 Leveler (Primer)	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KEB141YBL4, KEB141YWH4
(BLACK) (WHITE)



Illus. Part No. No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3181773	Membrane, Switch Black Model
	3184775	White Model
2	3183794	Bracket, Mounting Switch Membrane
3	3181702	Microcomputer
	3185648	Screw (2)

Illus. Part No. No. DESCRIPTION

4	3183705	Retainer, Bracket
	3182939	Screw (2)
5	3182985	Clip, Retainer (3)
6	3182162	Trim, Door (2)
7	3182150	Door, Latch Handle Black
	3182153	White
	3179847	Screw (2)
8	3183701	Trim, Panel
	3185647	Screw
9	3184321	Bracket (2)
	3182939	Screw (2)
10	3182147	Frame, Control Panel
11	3184567	Clip, Control Frame

Illus. Part No. No. DESCRIPTION

**FOLLOWING PARTS
NOT ILLUSTRATED**


LITERATURE PARTS

LIT3186506	Tech Sheet
LIT3183659	Installation Instructions
LIT3185642	Use & Care Guide

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH AND VENT PARTS

For Model: KEBI141YBL4, KEBI141YWH4
(BLACK) (WHITE)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			9	3184040	Spacer, Latch Handle	17	3183533	Bracket, Mounting
1	3183747	Module, Top		3184037	Screw (2)		3177991	Screw (4)
2	258076	Block, Terminal	10	3178410	Latch Mechanism	18	3183720	Blower, fan
	308043	Screw (2)	11	3177496	Plate, Mounting		3185647	Screw
4	3178668	Switch, latch		3177991	Screw	19	3183791	Tube, Vent
	98106	Screw	13	3183954	Nozzle, Vent Bottom		3185647	Screw
	254225	Screw	14	3183955	Nozzle, Vent Top	20	3149650	SPST Thermostat
5	3178185	Insulator, Switch		3185647	Screw		3185647	Screw
6	3177662	Guard, Latch	15	3183999	Box, Vent	21	3183799	Shield, Heat
7	3177969	Handle, Latch		4173231	Screw		3177991	Screw (2)
8	3184039	Knob, Latch Handle	16	3183964	End, Vent Box	22	3183953	Box, Vent
	3183294	Screw		3185647	Screw	23	4159035	Bushing
						24	313755	Seal, foam
						25	3185455	Baffle-Blower
							311773	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN LINER PARTS

For Model: KEBI141YBL4, KEBI141YWH4
(BLACK) (WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3185561	Liner, Oven
2	661415	Element, Broil
	3185648	Screw (4)
3	3147563	Grill, Broil
4	3147845	Pan, Broiler
5	3185309	Rack, Offset
6	3185310	Rack, Oven
7	661416	Element, Bake
8	3180694	Bracket, Element
	3185648	Screw (4)
9	3148440	Sensor, Heat
	3185648	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Model: KEB141YBL4, KEB141YWH4
(BLACK) (WHITE)





Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			7	3185458	Glass, Reflective	14	3182138	Spacer, Door Handle
1	3185499	Liner, Door	8	3185438	Plate, Latch Strike	15	3185456	Bushing, Door Handle
2	3178001	Screw, Black (2)	9	3185439	Retainer, Glass		3181637	Screw
3	3185462	Seal, Window	10	3185647	Screw		342043	Screw
4	3185457	Glass-Clear	11	3185459	Glass-Clear	16	3185471	Foil-Adhesive Backed
5	3185460	Insulation, Door	12	3181403	Frame, Door	17	3181701	Bumper, Door Glass
	3185437	Insulation Retainer		3185475	Glass, Door			
	4173601	Screw		3185477	Black Model			
			13	3185477	White Model			
				3182164	Black Model			
				3182167	White Model			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



WIRING HARNESS PARTS

For Model: KEBI141YBL4, KEBI141YWH4
(BLACK) (WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|---------|-----------------------------|
| 1 | 3187607 | Harness Wire (Door Switch) |
| 4 | 3185966 | Harness Wire (Oven) |
| 5 | 3179668 | Standoff, Wire |
| | 3148443 | Screw |
| 7 | 3184792 | Clamp, Wire |
| | 246132 | Screw |
| 8 | 3185952 | Harness, Wire (Latch Assy.) |
| 10 | 313438 | Clip, Harness |



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST