


# HOOD PARTS

For Model: KWCU360JSS0  
(Stainless)

36" PROFESSIONAL HOOD

**KitchenAid®**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# HOOD PARTS

For Model: KWCU360JSS0

(Stainless)


<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>	<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>	<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	8189613	Hood	8	4360062	Relief, Strain	15	8189604	Support, Back
2	8189612	Bracket, Hood	9	8189600	Nut	16	8189605	Chimney, Lower
3	8189611	Screw	10	4360158	Washer	17	8189606	Chimney, Upper
4	8189610	Bracket, Mounting	11	8189601	Plate (Rubber)	18	8189607	Chimney, 36"
5	4360318	Grommet	12	8189602	Transformer, 120V	19	4360320	Screw
6	4360001	Damper	13	8189603	Plate (Nylon)	20	8189608	Bracket, Chimney
7	4360190	Cover, Exhaust	14	4360310	Screw	22	8189609	Bracket, Upper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# VENTILATION PARTS

For Model: KWCU360JSS0

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# VENTILATION PARTS

For Model: KWCU360JSS0

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8189594	Filter, Grease	19	8189620	Button, Mtr Speed	34	8189629	Block, Terminal
2		Support, Side	20	4360257	Support, Filter	35	4360059	Bracket, Capacitor
	8189595	Left	21		Bracket, Diffuser	36	4360175	Capacitor
	8189617	Right		8189628	Left	37	4360255	Extension, Blower
3	8189596	Support, Light		8189625	Right	38	4360060	Cover, Box
4	8189593	Bulb, Halogen	22		Cover, Blower			
5	8189597	Holder, Bulb		4360188	Left			
6	8189598	Support, Bulb		4360179	Right			
7	8189599	Cover, Light	23	4360180	Nut, Locking			
8	4360062	Relief, Strain	24		Impeller, Blower			
9	8189614	Cover, Inlet		4360187	Left			
10	8189615	Spacer		4360181	Right			
11	8189616	Nameplate	25	4360185	Plate, Mtr Mount			
12	8189624	Cover, Switch	26	4360184	Housing, Fan			
13	8189623	Support, Switch	27	8189627	Motor, Blower			
14	8189621	Switch, On/Off	28	8189626	Nut, Motor			
15	8189622	Switch, Motor	29	4360345	Washer			
16	8189618	Button, On/Off	30	4360344	Washer, Star			
17	8189619	Box, Control	31	4360342	Spacer, Motor			
18	4360028	Lens, Indicator	32	4360347	Screw, Mtr Mount			
			33	4360056	Box, Capacitor			

<b><u>LITERATURE PARTS</u></b>		
	LIT8284829	Use & Care Guide
	LIT8189631	Wiring Diagram
<b><u>ACCESSORY PARTS</u></b>		
	8284756	Backsplash
	4378616	Wire Racks
	4378617	Rack Hanger Kits
		Utensil Bars
	4378618	Side
	4378619	Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST