


OVEN PARTS
For Model: KDRP767RSS01
(Stainless Steel)

36" KITCHENAID
FREE STANDING RANGE
DUAL FUEL STEAM



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: KDRP767RSS01

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	9758978	Installation Instructions
	9763071	Use & Care Guide
	9758979	Tech Sheet
	9759441	Conversion Instructions
	3191638	Safer Cooking Tips
	9759133	Safer Cooking Tips
	9762575	Cook Book
2	4449809	Screw, 8-18 x 3/8
3	4449743	Screw, 8-32 X 3/8
4	9758595	Retainer, Gasket
5	9761101	Pump, Drain (120v) (Includes Clamps)
6	4450118	Nut, (U-Type Clip)
7	9761161	Top, Chassis
8	4448520	Bumper, Door
9	4452158	Tube, Vent
10	4452163	Lens, Light
11	4448972	Oven Light Assy
	4449748	Screw
12	4452164	Bulb, Light
13		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand

Illus. No.	Part No.	DESCRIPTION
14	9762238	Frame, Front
15	8300142	Gasket, Door
16	4452152	Bracket, Mounting
17	4452260	Spacer, Foam
18	9758598	Boiler
19	8300184	Support, Insulation
20	9761145	Reservoir (Includes Clamps)
21	4455510	Bracket, Support
22	9762243	Gasket, Sensor
23	9761107	Sensor, Level
24	9760889	Latch, Motorized
25	4455641	Side, Chassis
26	9761160	Back, Chassis
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
30	4449154	Screw, 8-32 x .440
31	4449040	Screw, 8-18 x 3/8
32	3196176	Screw (2)
33	9758597	Orifice, Boiler

Illus. No.	Part No.	DESCRIPTION
34	9758596	Cover, Orifice Boiler
35	9762138	Hose, (Blue) (Pump to Outlet)
36	9762139	Hose (Gray) (Boiler to Pump)
37	4450249	Thermostat (TOD) (150c) SPST
38	9761154	Hose (Green) (Boil'r to Resv'r)
39	9761147	Clamp
40	9761146	Clamp
41	9762844	Screw
43	8300965	Base, Chassis
50	9758583	Cover, Back

**FOLLOWING PARTS
NOT ILLUSTRATED**


INSULATION

8300158	Insulation, Wrap
8300159	Insulation, Back

OVEN DOOR PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8300152	Door Liner
2	9760579	Hinge, Door R.Side
	9760580	L.Side
3	4449259	Glass, Inner
4	8300797	Insulation, Door
5	8300190	Retainer, Glass
7	4449263	Glass, Inner
8	4449743	Screw, 8-32 x 3/8

Illus. No.	Part No.	DESCRIPTION
9	9759634	Retainer, Glass
11	9759635	Spacer, Glass
12	8300162	Assy, Door Glass
13	4455852	Door Handle
14	4455803	Bracket, Handle Right Hand
	4455804	Left Hand
15	8302092	Bracket(2nd Glass)
16	3400832	Screw, 8-18 x 3/8


Illus. No.	Part No.	DESCRIPTION
18	8301084	Shield, Top Heat (Addition) (2)
19	8300971	Shield, Top Heat
20	4449809	Screw, 8-18 x 3/8
21	8300153	Seal, Door Top
22	9762144	Heat Shield (Btm)
24	3196184	Screw, 8-32 x .548
25	8302094	Bracket(3rd Glass)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
2	4456105	Element, Broil
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	9759437	Rack, Oven
7	8300204	Element, Hidden Bake

Illus. No.	Part No.	DESCRIPTION
9	4451583	Motor, Convection
10	4452226	Blade, Fan
11	4448418	Cover, Fan
12	4452227	Nut
13	9762242	Element, Convection


Illus. No.	Part No.	DESCRIPTION
14	8300799	Tray, Hidden Bake
15	8300800	Cover, Access
16	4449154	Screw, 8-32 x .440
17	4449809	Screw, 8-18 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	9758958	Panel, Control (Inc.Nuts,Clamps)
2	4453000	Bracket, Display
3	9758961	Bracket, Display Mounting
4	3196537	Screw, 8-18 x 3/8
5	9761103	Control, Zodiac
6	3196184	Screw, 6-19 x 1
7	4455806	Glass, Control Panel
8	9758960	Module, Display
9	2004333	Palnut
10	2005292	Nameplate

Illus. No.	Part No.	DESCRIPTION
11	9758968	Face, Control Panel
12	4455192	Bezel, Knob
13	4454970	Knob, Control
14	4455115	Knob, Temp/Time
15	9758966	Knob, Selector
16	4457218	Switch, Cancel Jumper
17	4452997	Switch, Enter
18	9758974	Button, Drain
19	9761600	Water, Inlet (Inc.Nuts,Clamps)


Illus. No.	Part No.	DESCRIPTION
20	9761146	Clamp
21	4457218	Switch, Cancel (Drain Pump)
23	9761149	Hose(Red)W/Clamps (Inlet to Resrv'r)
24	9761151	Hose(Clear)W/Clamps (Inlet to Valve)
25	4452842	Switch, Oven Light
26	4457152	Bezel, Temp Knob
27	3196178	Screw
28	9762136	Fitting, Drain (Includes Clamp)
29	9762671	Clamp

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	9758955	Vent, Exhaust
2	9758954	Vent-Top
3	9759837	Blower 60MM
4	9758953	Vent-Bottom
5	4452104	Transformer, Light
6	8300642	Transformer, Control

Illus. No.	Part No.	DESCRIPTION
7	4449809	Screw, 8-18 x 3/8
8	9758956	Bracket, Blower
9	9758999	Fuse-Thermo 105c 15a/120vac
11	4449868	Block, Terminal


Illus. No.	Part No.	DESCRIPTION
14	4452442	Side, Control Top
24	9761156	Control, Taurus (Appliance Mngr)
25	8302143	Suppressor
26	9758985	Control, Steam
27	4450800	Screw, 8-32 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	9760871	Cooktop
2	4455849	Burner Head
	4455979	Turbi (4)
	3368921	Auxi (6K) (2)
3	3368921	Screw, 7-18 x 3/4
4	4455243	Cap, Burner
	8284669	14k (4)
		6K (2)

Illus. No.	Part No.	DESCRIPTION
5		Orifice Holder
	4456622	Turbi (4)
	4456920	Auxi (2)
		(Incl. Orifice & Ignitor)
6	3177991	Screw, 8-18 x 1/4
7	4457331	Grate, Burner (3)


Illus. No.	Part No.	DESCRIPTION
9	4454962	Trim, Island
10	9762603	Support, Backsplash
11	9762605	Trim, Backsplash
12	3400837	Screw, 8-18 x 3/8
13	9782116	Ignitor
14	4449743	Screw
15	4455109	Plate, Simmer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX AND MANIFOLD PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8300231	Tubing, Gas Burner – RF
2	8300230	Tubing, Gas Burner – RR
3	8300187	Tubing, Gas Burner – LF
4	8300188	Tubing, Gas Burner – LR
5	8300229	Tubing, Gas Burner – CF
6	3400843	Screw, 8–18 x 3/8
7	4457248	Manifold
8	4456818	Valve, Burner Turbi (4) (Bronze)
	4456816	Small (2) (Red)
9	8523704	Bolt, Gas Valve (6)

Illus. No.	Part No.	DESCRIPTION
10	4456903	Burner Switch & Harness Assembly
11	9759091	Pressure Regulator
12	9762135	Box, Burner
13	3192439	Seal, Switch
14	4449809	Screw, 8–18 x 3/8
15	8285607	Right Side
	8285606	Left Side
16	9759140	Support, Rear
17	9758987	Support, Cooktop
18	3192811	Bracket, Burner
19	3177991	Screw, 8–18 x 1/4
20	9758964	Bracket, Valve
21	8301252	Tube, Manifold
22	9762133	Cover, Manifold
23	4453116	Adaptr, Compression 1/2" Male
	4453115	1/2" Female


Illus. No.	Part No.	DESCRIPTION
24	8284964	Cover, Burner Box
25	8522427	Module, Spark
26	9761102	Valve, Overflow
27	3196184	Screw, 8–32
28	9761150	Hose (White) (Valve to Resrv'r)
29	9761147	Clamp
30	3191387	Seal, Switch
31	4453191	Seal, Panel
32	4167077	Nut (2)
33	8300216	Bracket, Panel Support
34	8284796	Plug, Manifold
35	8300232	Tubing, Gas Burner – CR
36	4454974	Rail, Support

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: KDRP767RSS01

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4452803	Vent, Bottom Lower
2	4449809	Screw, 8-18 x 3/8
5	4452801	Deflector, Center
6	9761914	Vent, Center
7	4453327	Gasket
8	3196537	Screw, 8-18 x 3/8
9	9759092	Bracket, Mounting Regulator

Illus. No.	Part No.	DESCRIPTION
10	9759117	Foot
11	3400518	Screw, 5/16-12 x 5/8
12	4455644	Gusset
13	4455648	Support, Channel
14	W10015720	Brace, Rear

Illus. No.	Part No.	DESCRIPTION
15	4452804	Trim, Front Right Side
	4453205	Left Side
16	3400837	Screw, 8-18 x 3/8
17		Side Chassis
	9761934	Right Side
	9761933	Left Side
18	9759118	Plate
19	9762143	Tray, Drip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Model: KDRP767RSS01

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
ADHESIVE		
591014		Adhesive Loctite (1/3 oz.)
482338		Sealer, Silastic (3 oz.)
4453192		Seal, Ribbon Cable
4453191		Seal, Access Panel
2261590		Cleaner, S.steel

Illus. No.	Part No.	DESCRIPTION
SPLICING WIRES--25FT. LENGTH		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
WIRING HARNESS PARTS		
	9763620	Harness, Sensor
	9758951	Harness, Wire (Main)
	3196896	Clip, Wire
	4456628	Harness, Wire (Ignitor 39")
	4456627	Harness, Wire (Ignitor 28")
	9761098	Harness, Signal
	9761106	Wire, Jumper (Oven Light)
	9762508	Harness, Wire (DSI, 36", Steam)
	3191506	Bushing, Conduit
	1129449	Bushing
	8301668	Conduit
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground

Miscellaneous

	8301282	Conv. Kit (LP)
	4453141	Bracket, Anti-Tip (1")
	4453202	Bracket, Anti-Tip (1 3/4")

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST