

ECO-i™ Submittal Data



Building Life.

APR-RZP 1350BAB Kit Heat Recovery: Distribution Kits, Indoor Units

Job Name: _____
 Location: _____
 Engineer: _____
 Submitted to: _____
 Submitted by: _____
 Reference: _____


Approval: _____
 Date: _____
 Construction: _____
 Unit #: _____
 Drawing #: _____



APR-RZP1350BAB

Use: For indoor unit (Capacity after distribution joint is greater than 232.000 BTU/h and no more than 460.700 BTU/h.)

Example: (B below indicates inner diameter. Ⓟ below indicates outer diameter.)



Size	Part A	Part B	Part C	Part D	Part E	Part F	Part G	Part H	Part I
Inch	1 5/8"	1 3/8"	1 1/8"	1 1/8"	7/8"	3/4"	5/8"	1/2"	3/8"