




For technial support please visit http://www.laserco.com.au



LASER



PW-USBACDC User Manual



Please read carefully before use



Address: Unit 1, 6-8 Byfield St, North Ryde, NSW 2113 AUSTRALIA

PW-USBACDC User Manual

COMPONENTS IN THE BOX

AC plug	Australia / New Zealand 240v AC plug
Charger body	100v - 240v transformer (self switching)
DC plug	12v DC Car (Cigarette socket) adaptor
USB connectors (x 2)	Twin USB ports for charging

FEATURES

- > Charge almost any 5V USB device such as iPod [™], digital cameras, MP3/ 4 players or mobile phones that charge using a USB cable.
- > Simply plug into any wall (240v) or car (12vDC) socket and start charging.
- > Convenient slimline design.
- > Two USB sockets for increased versatility

IMPORTANT SAFETY INSTRUCTIONS

- > Read and observe all warnings on the USB charger and in this user manual .
- $\,>\,$ Devices connected to the USB charger should not exceed 5.3Volts
- > Do not use the USB charger in the moist places or close to water.
- > Safe operating environment: 0 to 45 degrees Celsius

OPERATION

- > Select either AC (100-240VAC) plug or DC (12-14vDC) plug to be used
- > Connect the USB device(s) to one or both of the USB output terminals
- > Charging will commence immediately (no switches required)

TECHNICAL SPECIFICATIONS

- > AC input: 100VAC~240V AC 50/60Hz
- > DC input: 12VDC~24VDC
- > Rated output: 5V DC (standard)
- > USB 1 and 2 ports: 0.5A max current > SIZE:18X18X5.5(L X W X H)
- > WEIGHT:260g

TROUBLESHOOTING

- > Voltage of device does not correspond with that of USB adapter (5v; 0.5A per device)
- Refer to the user manual that came with your device.
- > Improper connection between your device and the USB adapter.

 Make sure that the USB cable has the correct plug and is properly inserted into the device and the USB adapter.
- Device is not charging
 Some products require a PC or dedicated verification signal for battery charge & may need a PC to charge
- > Can not charge with car kit plug in the car Check the in built fuse in the DC plug and replace if necessary / check ignition on or vehicle fuse.

WARRANTY

- > 1 year limited warranty
- $\,{}^{>}$ Warranty does not cover owner's negligence, accidental damage, misuse, normal wear and tear



7