





## SkipDr Manual

### Quick Start Guide



### **SPRAY**

SkipDr® Rejuvenating Fluid lightly onto the play-side of the disc (do not spray on the label-side).



### **REPAIR**

the disc by inserting it into the SkipDr® Disc Repair System with play-side toward the FlexiWheel™. Turn the crank handle clockwise until the disc completes two full rotations. The disc will move at a much slower rate than the crank handle. Repeat as necessary.



### **DRY + SHINE**

Dry the play side of the disc with the blue drying cloth. Then place the disc on top of the drying cloth and buff using the white buffing square. **NOTE:** Thorough buffing is crucial for perfect playback. It is normal for a slight, harmless radial pattern to remain on the disc after buffing. Repeat step as necessary. The Flexiwheel™ will repair up to 25 discs.

**WARNING: Not for use with Blu-ray™ or Playstation® 3 discs.**