

TOSHIBA



**TOSHIBA AMERICA INFORMATION SYSTEMS
STORAGE DEVICE DIVISION
IRVINE, CALIFORNIA**

**SD-R2612
CD-RW/DVD-ROM COMBINATION MOBILE DRIVE
USER MANUAL**

CONTENTS

Introduction.....	1
Setup	3
Using the CD-RW/DVD-ROM Combo Drive	4
Troubleshooting.....	7
Specifications	8
Drive Connectors.....	11

INTRODUCTION – SD-R2612

General Features

CD-RW disc write/rewrite at 4X – 24X

CD-R disc write at 4X - 24X

3-way Disc Eject (eject button, software, emergency eject hole)

Average Access Time

CD	130ms
DVD-ROM (single)	130ms
DVD-ROM (dual)	150ms
DVD-RAM	250ms

Horizontal or Vertical Mount

2MByte Buffer

Playback interchangeability for CD-ROM and DVD-ROM discs

Regionalization (RPC2 compliance) (DVD)

BUS Interface ATAPI

Format Compatibility

CD:


- CD-DA (Red Book) - Standard Audio CD & CD-TEXT
- CD-ROM (Yellow Book Mode1 & 2) - Standard Data\
- CD-ROM XA (Mode2 Form1 & 2) - Photo CD, Multi-Session
- CD-I /FMV (Green Book, Mode2 Form1 & 2, Ready, Bridge)
- CD-Extra/ CD-Plus (Blue Book) - Audio & Text/Video Video-
- CD (White Book) - MPEG1 Video

DVD

- DVD DVD-ROM (Book 1.02)
- DVD-Video (Book 1.1)
- DVD-R (Book 1.0, 3.9G)
- DVD-R (Book 2.0, 4.7G) - General & Authoring
- DVD+R (Version 1.0) DVD±RW DVD-RAM P
- DVD+R (Version 1.0)
- DVD±RW
- DVD-RAM

Front Panel

Figure 1. SD-R2612 CD-RW/DVD Combo Drive Front Panel



Loading Tray	Load disc using tray.
Busy Indicator	The LED lights green or amber when the drive is operating (LED is amber when drive is writing.)
Eject Button	The Eject button is used to open the disc tray so you can install or remove a disc.
Emergency Eject Hole	The emergency eject hole is to be used only when the Loading Tray will not open when Eject button is pressed.

SETUP – SD-R2612

Toshiba recommends that only trained professionals install this CD-RW/DVD-ROM Combo drive into your laptop/notebook.

Installation Notes

- The SD-R2612 CD-RW/DVD-ROM Combo drive has no jumpers that need to be set
- Mounting orientation: 15° (horizontally), 15° vertically (volume control in down position), 30° (drive with volume control in up position).
- When mounting drive use 4 M2-PO.4 tapping holes located on the left and right sides of drive.
- When mounting drive, the tightening torque of the four screws must be even. Recommended screw tightening torque is 2N
- For clearance around the front bezel, it is recommended that a clearance of more than 0.8mm should be left in all directions.

Software Driver

Toshiba's SD-R2612 drive does not require any unique device drivers for Windows '98/2000/XP/NT. After installing your drive and re-booting, your system should recognize your drive. Win '98/2000/XP/NT Operating Systems support all Toshiba's ATAPI drives natively. If you prefer using DOS, download the ATAPI driver from our web site.

USING THE CD-RW/DVD-ROM Combo Drive – SD-R2612

Drive Operation

Inserting Media

To insert media perform the following steps:




Figure 1. Inserting Disc

1. Open the drive's loading tray by pressing the Eject Button and pulling out the tray.
2. Place media disc into drive's loading tray, and lightly press down on the inner portion of the disc.
3. Gently close the disc tray.

Removing Media

To remove media disc from the drive, perform the following steps:

1. Open the loading tray by pressing the Eject Button, and pulling tray out.
2. Grasp disc by it's outer edge, and lift out of loading tray.
3. Gently close the loading tray.

Usage Guidelines

- Keep the disc tray closed when not using the CD-RW/DVD-ROM Combo drive
- Do not press down on the disc tray when opening or closing it.
- Do not place objects on the disc tray
- Never use a damaged, broken, or deformed disc
- Do not press the Eject button while the drive is playing a DVD movie or accessing a disc. To stop a DVD movie, click Stop button in the DVD player application program



NOTE: High-speed drives spin the disc at a high rotational speed. If a disc has printing on only half of the disc, or if there is a slight imbalance in the disc, the imbalance is greatly magnified by the high speed, causing the drive to vibrate or produce a fan-like noise. These effects are inherent in the high-speed technology and do not indicate a problem with the drive.

Regional Coding

Region Protection Coding (RPC) of DVD Discs: this feature is supported on DVD Players and is used with DVD-Video Discs (i.e. movies). Currently, the motion picture industry has divided the world into different regional "zones." These regions or "zones" correlate to the regional markets into which the motion picture industry releases movies. Simply put, RPC Codes are placed on Movie Discs marketed throughout the world based on the region of the world where they are being sold. These RPC codes help to control and prevent the pirating of new release movies into other motion picture market regions prior to their true release dates within those markets.

The SD-R2612 DVD-ROM/CD-RW drive supports the current RPC phase 2 industry specifications. This means that when the DVD-ROM drive ships from the factory it is set to the region for which the Operating System was intended. In other words the drive is set to support the Region 1 (North America) Operating System and will only play Region 1 (North America) DVD-Video movie discs.

Emergency Ejection



CAUTION: The following procedure is intended only as a last resort when pressing the eject button fails to open the Loading Tray.

1. Turn computer power OFF by properly shutting down system.
2. Insert a solid bar (i.e. large paper clip) into Emergency Eject hole and push in as shown in the picture below.
3. Loading tray will open/eject.



Figure 2.Using Emergency Eject

Handling Media

DVD media is sensitive to dust and fingerprints. Carefully handle media by its edges only. If a DVD movie skips or hangs during playback, clean the media. Most DVD video playback issues are media-related and can be remedied by proper handling and care of media.

Cleaning Media

Try to avoid touching the read area (underside) of the disc as dirt and smears will degrade the disc accessing speed.

If the disc becomes dirty wipe it with a damp soft cloth. Avoid cleaning in a circular motion, but rather from the inner side outward.

TROUBLESHOOTING – SD-R2612

Problem	Solution
Disc tray cannot be opened	<ul style="list-style-type: none"> • Check that there is power to drive. • Use Emergency Eject instructions to open tray.
Drive is not recognized by system	<ul style="list-style-type: none"> • Is the drive connected properly? Are all cables plugged in properly (e.g. Power Cable, Interface Cable and Audio Cables). • Is the software driver loaded? On a step-by-step (F8) Boot of the system is the CD-RW/DVD-ROM Combo drive recognized? (BIOS / DOS reports "device driver not found" or "no valid drivers selected."). If not, Contact Technical Support. • Has the CD-RW/DVD-ROM Combo drive software driver been corrupted by a virus. Run a Virus Scan program and repair if possible. Contact Technical Support if the Virus renders the CD-RW/DVD-ROM Combo drive software drivers not useable.
Drive is not recognized by system during Boot process, but is recognized by the Operating System (i.e. XP, Win2000, Win98, Win NT, etc.)	<ul style="list-style-type: none"> • Is the CD-RW/DVD-ROM Combo drive software driver loaded? On a step-by-step (F8) Boot of the system is the CD-RW/DVD-ROM Combo drive recognized? (BIOS / DOS reports "device driver not found" or "no valid DVD drivers selected."). If not, Contact Technical Support. • Has the Windows CD-RW/DVD-ROM Combo drive software driver program been corrupted by a virus. Run a Virus Scan program and repair if possible. Contact Technical Support if the Virus renders the software drivers not useable.
BUSY Indicator LED flashes slowly	<ul style="list-style-type: none"> • The disc may be dirty Clean it with a soft damp cloth. Avoid cleaning the disc using a circular motion. The disc should be wiped in a radial direction. That is, from the inner side outward. • The laser lens may have become cloudy or blocked by particulate matter. Please contact Technical Support.
BUSY Indicator LED is constantly ON	<ul style="list-style-type: none"> • Possible Hardware Problem. Please contact Technical Support.
DVD-ROM can not play a DVD in the drive or certain types of CD media (i.e. CD-plus, etc.)	<ul style="list-style-type: none"> • Is the CD-RW/DVD-ROM Combo drive driver loaded • Is the DVD disc the correct format for the type of system that you are using? (i.e. on a PC an ISO9660 IBM compatible PC format as opposed to Apple/Mac HFS disc or UNIX disc formats which will not function). • Do you have the correct software applications program/drivers installed to run a DVD disc? • Has the Windows CD-RW/DVD-ROM Combo drive software driver program been corrupted by a virus. Run a Virus Scan program and repair if possible. Contact Technical Support if the Virus renders the software drivers not useable.

SPECIFICATIONS –SD-R2612

General

Interface: ATAPI

Format Compatibility

CD:

- CD-DA (Red Book) - Standard Audio CD & CD-TEXT
- CD-ROM (Yellow Book Mode1 & 2) - Standard Data\
- CD-ROM XA (Mode2 Form1 & 2) - Photo CD, Multi-Session
- CD-I /FMV (Green Book, Mode2 Form1 & 2, Ready, Bridge)
- CD-Extra/ CD-Plus (Blue Book) - Audio & Text/Video
- Video-CD (White Book) - MPEG1 Video

DVD

- DVD DVD-ROM (Book 1.02)
- DVD-Video (Book 1.1)
- DVD-R (Book 1.0, 3.9G)
- DVD-R (Book 2.0, 4.7G) - General & Authoring
- DVD+R (Version 1.0) DVD±RW DVD-RAM P
- DVD+R (Version 1.0)
- DVD±RW
- DVD-RAM



Note: All DVD/CD formats, except CD-Red Book (audio), require additional application specific software and/or hardware. The drive is capable of reading these data formats. However, in order to run applications that use these formats, you must first have the required software and/or hardware.

Data Disc Capacities

DVD-ROM	4.377GB (DVD-5)
	7.959GB (DVD-9)
	8.754GB (DVD-10)
	15.917GB (DVD-18)
DVD-R (Ver 1)	3.679GB
DVD-R (Ver 2.0)	4.377GB
DVD-RAM (Ver 2.1)	4.377GB
CD	656.5MB (mode 1)
	748.8MB (mode 2)

Performance

Transfer Rate

DVD (Single)	10,800KB/second max (8X max)
DVD (Dual)	8,100KB/second max (6X max)
DVD+/-R	8,100KB/second max (6X max)
DVD+/-RW	8,100KB/second max (6X max)
DVD-RAM (Ver 2.1)	5,400KB/second max (4X max)
CD-ROM/R (Read, Mode 1)	3,600KB/second (24X max)
CD-RW Read (Mode 1)	3,600KB/second (24X max)

Random Access Time

CD-ROM	130ms
CD-RW	130ms
DVD (single)	130ms
DVD (dual)	150ms
DVD-R/+R	150ms
DVD-RW/+RW	150ms
DVD-RAM	250ms

Data Error Rate

DVD-ROM	10^{-15} Max
CD-ROM	10^{-12} Max (Mode 1)
	10^{-9} Max (Mode 2)

Data Buffer

2MB

Reliability

MTBF

	80,000 hours
• Power ON Hours	2,000 hours/year
• SEQ Read	42.6%
• Seek	9.3%
• Write	31%
• Power ON/OFF	7.7%
• Drawer Test	9.3%

Drive Lifetime

5 years

Drawer Load/Release

10,000 times

Environmental

Ambient Temperature	
Operating	5° to 50° C (41° to 122° F)
Storage	-40° to 65° C (-40° to 149° F)
Relative Humidity	
Operating	10% to 90%
Storage/Shipping	5% to 95% (wet bulb 40° C max)
Vibration	
Operating (5 to 500 Hz) (read)	2.45 m/s ² (0.25G) (O-P)
Operating (5 to 500Hz) (write)	2.45 m/s ² (0.25G) (O-P)
Non-operating (10 to 500Hz)	9.8 m/s ² (1.0G) (O-P)
Packing (10 to 25 Hz)	9.8 m/s ² (1.0G) (O-P)
Shock (Non-operating)	490 m/s ² [50G]
Acoustical Noise	40dB

Power

DC Voltage and Current Requirements	+5V ±5% (Operating)
-------------------------------------	---------------------

Physical

Height	0.5" (12.7mm)
Width	5.04" (128mm)
Depth	5.00" (127mm)
Weight	6.35oz (.18kg)

Connectors

IDE Interface Connector	50 Pin I/F ATAPI Standard
-------------------------	---------------------------

Regulatory

The SD-R2612 DVD Writeable drive has been certified by the following regulatory agencies:

- UL 1950
- CSA C22.2 No. 950
- TUV (EN60950I)
- CE standard
- DHHS 21 CFR Sub-Chapter J
- FDA CFR21, EN60825

Drive Connectors –SD-R2612



Figure 1. SD-R2612 DVD Writeable Drive Rear Panel – Connector

ATAPI Connector A 50-pin ATAPI interface connector is found at the rear of the SD-R2612 CD-RW/DVD-ROM Combo drive. Connecting cable should use Japan Aviation Electronics Industry Limited KX14-50Series L or equivalent connector.

Table 1. Interface Pin Assignments

PIN NO.	I/O	SIGNAL NAME	PIN NO.	I/O	SIGNAL NAME
1	O	Audio L-CH	2	O	Audio R-CH
3		Audio Ground	4		Digital Ground
5	I	/RESET	6	I/O	DD8
7	I/O	DD7	8	I/O	DD9
9	I/O	DD6	10	I/O	DD10
11	I/O	DD5	12	I/O	DD11
13	I/O	DD4	14	I/O	DD12
15	I/O	DD3	16	I/O	DD13
17	I/O	DD2	18	I/O	DD14
19	I/O	DD1	20	I/O	DD15
21	I/O	DD0	22	O	DMARQ
23		Ground	24	I	/DIOR: / HDMARDT: HSTROBE
25	I	/DIIOW:STOP	26		Ground
27	O	IORDY: / DDMARDY: DSTROBE	28	I	/DMACK
29	O	INTRQ	30	O	/IOCS16
31	I	DA1	32	I/O	/PDIAG
33	I	DA0	34	I	DA2
35	I	/CS1FX	36	I	/CS3FX
37	I/O	/DASP	38	I	+5V (Motor)
39	I	+5V (Motor)	40	I	+5V (Motor)
41	I	+5V (Logic)	42	I	+5V (Logic)
43		Ground	44		Ground
45		Ground	46		Ground
47	I	CSEL	48		Ground
49	I	Vendor Unique*	50	I	Vendor Unique*

**Vender Unique, don't connect pins*