

KH 85



(GB) Operating and safety instructions

# Operating instructions

bifipett

Kompernaß Handelsgesellschaft mbH Burgstraße 21 · D-44867 Bochum (Germany)







# Safety advice

- 1. Before using your citrus press for the first time, please read through the operating instructions and this safety advice carefully.
- The citrus press is to be connected only to an earthed mains socket which has properly installed in accordance with the applicable regulations. To avoid accidents, never operate several household appliances from the same socket at the same time.
- 3. This citrus press is intended only for domestic use.
- 4. Do not use this citrus press outside.
- 5. Do not leave the citrus press to operate unattended or allow children to use it.
- 6. Handle the moving parts of the device with extreme care and caution.
- 7. Do not remove the mains plug by pulling on the mains cable. Grasp and pull on the plug itself.
- 8. Do not allow the mains cable to hang down.
- 9. Do not immerse the device in water or hold it under running water to clean it. Please refer to the section "Cleaning".
- 10.Keep this safety advice for later reference and if necessary pass it on to third parties.
- 11. Should the mains cable become damaged, it must be replaced by the manufacturer, his service centre or electrical equipment repair centre. To prevent dangerous circumstances from arising, all repairs of electrical equipment must be carried out by suitably qualified electricians

## Specification

- 1) Lid
- ② Press cone
- ③ Juice filter/sieve
- ④ Sieve holder / juice container
- Spout
- 6 Housing with cord storage (on underside)

#### Before first use

- Before using your citrus press for the first time check that the local mains electricity supply corresponds with that indicated on the citrus press.
- Before using the citrus press for the first time clean the press cone, juice filter, juice container and spout. Please refer to the section "Cleaning".
- 1. Insert the plug into the mains socket.
- 2. Wind up any excess cable on to the underside of the citrus press and fix the cable in the recess at the back of the underside of the base.
- 3. Place the device down on a flat sturdy surface. Always keep the citrus press out of reach of children.

#### Using the citrus press

Note: Before juicing we recommend that you roll the fruit on the work surface whilst pressing down gently. In this way you will obtain-more juice. We also recommend that you clean the citrus press immediately after use. Please refer to the section on "Cleaning".

- 1. Open the lid.
- 2. Place the sieve holder / juice container in the device.

- 3. Select the appropriate juice press. The small press piece is intended for fruit with little flesh. The larger press is placed on the smaller so that juice and flesh can be obtained (ideal for pressing larger fruit such as grapefruit etc.).
- 4. Place the sieve with the small press (or both presses) on to the motor spindle. The citrus press tongue and the juice collector handle must be in line with one another.
- 5. Insert the plug into the mains socket.
- 6. Place a glass under the spout.
- 7. To open the spout press it downwards.
- 8. Press a fruit half on to the press the device starts automatically and stops when the fruit is removed. The alternating left-right movement of the press obtains the best yield of juice.
- 9. Push up the spout before you remove the glass from beneath it. This ensures that the spout does not continue to drip.
- 10. When the citrus press is not needed any longer, pull out the plug and remove any fruit residue from the sieve.

#### Cleaning

- 1. Before cleaning always remove the plug from the mains socket.
- 2. Remove the press cone, juice filter and juice container from the device.
- 3. Press the spout fully downwards and clean it thoroughly. Note: The spout cannot be removed from the device.
- 4. Clean the press cone, juice filter and juice container under running water. Note: These parts can be washed in a dishwasher. Place the parts in the upper basket of the dishwasher.
- 5. Clean the citrus press housing with a moist cloth only. To remove stubborn dirt put a little detergent on the cloth. Never use harsh cleaning or scouring agents. Never immerse the motor housing in water or wash it under running water.

### STATEMENT OF CONFORMITY

We, Kompernaß Handelsgesellschaft mbH, Burgstr. 21, D-44867 Bochum, Germany, hereby declare that this product conforms with the following EC regulations:

EC low voltage regulations: Electromagnetic compatibility: Applicable harmonised standards:	73/23/EEC, 93/68 89/336 EEC, 92/31 EN 55014:2000 +A1, EN 55014-2:1997 EN 61000-3-2:2000, EN 61000-3-3:1995 +A1 EN 60335-1:1994 +A1:1996 +A2:2000 +A13:1998 +A14:1998 +A15:2000 +A16:2001
	EN 60335-2-14:1996 +A11 +A1 +A2

Model type/Description: CITRUS PRESS BIFINETT KH 85

Bochum, 30.09.2002

Hans Kompernaß - Managing Director -



bifinett