


For Models: KURS24LSBS00

(Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KURS24LSBS00


(Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12		Frame, Side	24	4344824	Clip, Harness
	4344903	Energy Guide		4344789	Left Side	25	4344822	Harness, Wire
	2300274	Use & Care Guide		4344790	Right Side	26	4344827	Screw
	4344902	Wiring Diagram	13	4344771	Bracket, Grille	27	4344792	Thermal Fuse
2		Cabinet (Not A Service Part)	14	4344876	Evaporator Fan Assembly	28	4344793	Screw
3	4344739	Lens, Light	15	4344766	Thermostat	29	4344791	Screw
4	4344740	Bulb, Light	16	4344768	Knob, Thermostat	30	4344783	Fan Blade
5	4344746	Heater, Defrost	17	4344767	Switch, Plunger	31	4344878	Screw
6	4344747	Heat Shield	18	4344826	Screw	32	4344865	Evaporator Fan Motor
7	4344761	Grille	19	4344797	Screw	33	4344877	Harness, Wire
8	4344762	Plate, Bottom	20	4344819	Clip, Grille	34	4344832	Screw, Ground
9	4344763	Foot, Leveling	21	4344825	Screw	35	4344778	Grommet, Fan Motor
10	4344764	Brace, Support	22	4344823	Seal	36	4344899	Bracket, Motor
11	4344765	Control Box	23		Frame, Support	37		Evaporator (Not Serviced)
				4344821	Right			
				4344820	Left			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: KURS24LSBS00
(Black)




Illus. No.	Part No.	DESCRIPTION
1	4344741	Wire Shelf
2	4344742	Bracket, Shelf
	4344743	Right Side
	4344743	Left Side
3	4344744	Basket, Crisper
4	4344745	Shelf, Crisper
5	4344748	Ladder, Shelf
	4344748	Left Side
	4344749	Right Side
6	4344794	Screw
7	4344795	Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KURS24LSBS00
(Black)



Illus. No.	Part No.	DESCRIPTION
1	4344807	Door Assembly (Includes Gasket)
2	4344751	Beverage Holder
3	4344752	Door Bin
4	4344787	Hinge, Bottom
5	4344754	Hinge, Top
6	4344755	Spacer, Top Hinge
7	4344798	Spacer, Bottom Hinge
8	4344757	Actuator, Switch
9	4344758	Door Stop
10	4344759	Door Gasket

Illus. No.	Part No.	DESCRIPTION
11	4344810	Handle, Door
12	4344812	Door Skin, Stainless Steel
13	4344760	Washer
14	4344788	Spacer, Door
15	4344809	Plate
16	4344796	Screw
17	4344906	Screw, Lower Hinge
	4344906	Quantity 1
	4344797	Quantity 3
18	4344827	Screw

Illus. No.	Part No.	DESCRIPTION
19	4344799	Screw
20	4344801	Screw
21	4344808	Screw
22	4344813	Nameplate
OPTIONAL PARTS NOT ILLUSTRATED		
	8171420	Cleaner, Stainless Steel (12 oz)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

