




mellerware®

Whip Master Milk Frother



complies with
INTERNATIONAL
IEC60335
SAFETY SPECIFICATIONS

CE
2 YEAR
GUARANTEE

Model:
TWM007

PLEASE READ ALL INSTRUCTIONS BEFORE USE

2 year guarantee





How to Use and Clean

1. Insert 2 x AA batteries (not included) into the space at the top of the frother.
2. The milk may be in a cup, saucepan, jug or container. If the milk is at room temperature or a little warmer it assists with frothing, Very cold milk can be warmed in a microwave oven or in a saucepan on the cooktop. (do no over heat)
3. Hold the frother stem in the milk to be frothed and switch on. Be sure the container of milk is only 1/3 filled, to allow room for the frothing process. Rotate and move the frother in and out of the milk. Your milk will be light and frothy in seconds, perfect for cappuccino or children drinks.
4. To clean simply immerse the stem into a cup or jug of hot water or directly under the tap and

switch on. (do not immerse the body)

The body of the frother must not be submersed in liquid at any time. Only the stem can be inserted in liquid. If the body needs cleaning, wipe with a damp cloth and dry.



creative housewares

27 Nourse Avenue Epping 2 Cape Town
P.O. Box 975 Eppindust 7475 South Africa
Tel: +27 21 534 8114 Fax: +27 21 534 8086
Service Centre Share Call: 086 111 5006
web: www.creativehousewares.co.za

