## **Tanaka**


# Parts Catalog

### **Water Pump**

Model: QCP-121

All Units Prior To Serial Number K 171825


### FIG.1 ENGINE



	JER						7	1 145
REF	NER PARTIER	PARTHAME	/	\$			SERVA NE	R REMARKS
1-001 1-002	002-00500-804	CYLINDER COMP. CYLINDER GASKET	1	Ĺ				
1-003	018-00502-200	SPARK PLUG BM6A	11					•
1-004	031-00500-200	PISTON	1					
1-005	037-00000-200	PISTON PIN 9X24 PISTON PIN CIRCLIP	1 2					
1-007	041-00000-200		1	].				
1-007	041-00000-200		2	I	-H1 H1		00	,
1-008	046-00532-802	CRANK SHAFT COMP.	2		- D O	187	79	
1-008	048-00573-800   068-02000-200	CRANK SHAFT COMP. WOOD-RUFF KEY 3X13X5		N	Do	187	80-	
1-010		CRANK SHAFT WASHER 15.2X22	li					
1-011	072-00531-900	CRANK CASE ASS'Y	1	R	-D0	187	79	
1-011	072-00557-900	CRANK CASE ASS'Y	1				80-	
1-012		BALL BEARING #6201, 32NH/OD OIL SEAL 12287	1					
1-014	038-00000-200	PISTON PIN BUSHING	$\begin{vmatrix} 1 \\ 1 \\ 1 \end{vmatrix}$	M				RLA
1-016	999-61600-200	BALL BEARING #6002, 32NH/OD	1					
1-017		OIL SEAL 15257	1					
1-019		CRANK CASE GASKET NUFFLER GASKET	1					
1-021	990-11060-201		3	M				
1-021	990-11060-181	SCREV 6X18	3 3	"				
1-022	992-10060-012	S. VASHER B	3					
1-024	990-11060-221		3					
1-025	992-10060-012   159-20702-900	S.VASHER B  CONTACT BREAKER ASS'Y	3		-00	187	70	
1-026,2	159-21401-871	IGNITOR COMP. TTI-1E	li	N	-F0			
1-026	159-21401-872	IGNITOR COMP. TTI-1F IGNITOR LEAD WIRE COMP., R110M	1	H			72- 72-	
					FU	200	172-	
1-029	246-20701-201	NAGNETO CAM  CAM SUPPORT SPRING	11	D			80- 80-	
1-031	191-00501-201	CONTACT POINT COVER	i	D			80-	
1-033		MAGNETO ROTOR ASS'Y	1					
1-034	992-01050-011 788-00801-203		2 2					
1-028	822-00801-200	CTARTED DAUG CUIM A CT						
1-036	790-00601-200	STARTER PAUL SHIM 0.6T STARTER PAUL SPRING	2					
1-038	793-10200-200	ISTEP BOLT	2	R	-B0			
1-038	793-10200-201 793-10200-202	ISTEP BOLT	2	D	-J0	752 752	60 61-	
1-039	065-00000-200	FLYWHEEL WASHER	ī	•				
1-040	066-00000-200	FLYWHEEL NUT 12	1					
1-041	990-11040-081		1	D			80-	
1-042	992-10040-012 991-01030-011			D D			80 <i>-</i> 80-	
1-044	992-10030-012	S. VASHER 3	1	D	DO	187	80-	
1-045	992-01030-011	AVZHEK 3	1	D	DO	187	80-	İ
	205-00501-200			D			80-	
1-047	177-20701-801	CONDENSER COMP. IGNITION COIL COMP.	1	D			80-	
1-048	167-20741-800	IGNITION COIL COMP.	1	N	-DO		79 80-	
1-049	157-04000-900 202-10200-201	SPARK PLUG CAP ASS'Y	1					
1 1			1					
		FAN CASE LIGHT ORANGE		I	-CO			
	990-11050-201	FAN CASE, LIGHT ORANGE SCREW 5X20	1 3		LU	<b>3</b> 5 3	85-	
1-055	992-10050-012	S. VASHER 5	3				:	
	990-11040-101 992-10040-012		3					
	990-11050-201		1 1	ار			Ţ	
1-058	990-11050-401	SCREW 5X40	2 2	Ħ				]
	992-10050-012	IS. VASHER 5	2	_				
- To be co	ont'd —							


RET HER PARTER	PARTUANE	ST. SERVINER REMARKS
1-060 992-00050-011 1-061 990-11040-081	SHALL WASHER 5	2 3 D C064123-
1-082 992-10040-012		3 D C064123-
1-063 992-01040-011 1-064 132-00502-201	FLASH PAN	3 D C064123- 1 D C064123-
1-067.1 990-11040-161 1-067 990-11040-081 1-068.1 992-10040-012	SCREV 4X8	2   -F020571 1   N   F020572- -F020571
1-068 992-10040-012	S. VASHER 4	1 -F020572
1-070	SCREW 4X8	1 N 1 N D018780-
	SMALL WASHER 4	1 N D018780- -D018779
1-072 198-00701-200		1
	PRINARY CORD COMP., SPECIAL STOP CORD COMP.	1 N D018780- 1 -D018779 1 N D018780-
1-074 070-00601-201 1-075 198-01046-900	CRANK SHAFT VASHER 12.2X18 CORD CLANP ASS'Y	2 1 I -F186220
1-075   198-05015-800 1-077   990-11040-081	CORD CLAMP COMP.	1 F186221- 2 D D018780-
1-078 992-01040-011		2 D D018780-
:		

#### FIG.2 CARBURETOR




REF	NEP PARTIER	CARRIESTOR ASSIV	SE SERVINER REMARKS
2-000 2-000 2-000 2-000 2-002 2-003	455-20426-901 455-20440-901 455-20440-902 455-20441-900	CARBURETOR ASS Y CARBURETOR ASS Y CARBURETOR ASS Y FLOAT CHAMBER GASKET	1 I -D019779 1 I I -D041399 1 M D041400-
2-004 2-004 2-005 2-005 2-006 2-006	605-20400-200	NEEDLE JET 2080 FLOAT ARM PIN FLOAT ARM PIN FLOAT	1 H 1 1 H 1 1 H 1 1 H 1 1 H 1 1 H 1 1 H 1 1 H 1 1 H 1 1 H 1 1 H 1
2-007 2-007 2-008 2-009 2-010 2-011	599-20426-054 599-2001T-540 606-20428-200 629-20400-200 627-20400-200 990-11040-100	MAIN JET #54 FLOAT CHAMBER DRAIN PLUG GASKET DRAIN PLUG	1 M 1 1 1 1 1 1 2 M
2-011 2-013.1 2-013 2-014 2-015 2-016	994-14040-120 603-20400-900 603-20400-200 802-20200-200	SCREW 4X12S NEEDLE VALVE ASS'Y NEEDLE VALVE VALVE SEAT FUEL INLET GASKET	
2-016 2-017 2-017 2-018 2-018 2-021	499-20200-200 543-20426-200 543-20200-200 561-20426-900 561-20436-900		
2-021 2-022 2-022 2-023 2-024	591-2001T-200 592-20426-900 592-2008T-920 593-20400-200 619-20400-200	THROTTLE VALVE 0.5X1.5 JET NEEDLE ASS'Y JET NEEDLE ASS'Y #073 JET NEEDLE CLIP THROTTLE SPRING RECEIVE	
2-024 2-025 2-025 2-026 2-027 2-028	594-20400-200 594-20436-200 595-20426-200 500-00532-900 504-00532-200	LINK MOTION ARM ASS'Y LINK MOTION NUT	
2-028 2-029 2-037	495-20426-800	LINK MOTION NUT LINK MOTION CABLE COMP. FLANGE GASKET	

FIG.3 AIR CLEANER & MUFFLER




REF HER PARTIER	PARTHAME	SERVICE REMARKS
3-000,1 410-00700-91 3-000 410-00440-90 3-001 424-00532-20 3-002 421-00532-20 3-003 425-00532-20	CLEANER ASS'Y DAIR CLEANER ASS'Y DAIR CLEANER COVER CCLEANER ELEMENT CCLEANER HOLDER A CCLEANER HOLDER B	1
3-008   393-00005-20	SCREW 4X16	2 N D118691- 2 N D118691- 1 -A176334 1 P A176335-
3-012 990-11050-14 3-013 992-10050-01	2 S.VASHER 5 D MUFFLER ASS'Y I SCREW 5X14	2 2 1 2 2 1 N C091881-
3-015 3-018 3-017 3-018.1 3-018.1 3-018.1 3-018.7 3-018.7 3-018.7 3-018.7 3-018.7 3-018.7 706-00550-80	2 S.VASHER 6 L VASHER 6 D MUFFLER COMP.	2 N C091881- 2 N C091881- 2 N C091881- 1 R -C091880 -D019080 D019081-
3-023   732-00573-80 3-024   722-00573-20 3-025   992-10040-01 3-026   990-11040-10		1 N D019081- 1 N D019081- 1 N D019081- 2 N D019081- 2 N D019081- 1 D D118691-
3-029 3-030 426-00700-21 446-00700-22 3-031 3-032 990-11040-10 3-033 992-10040-01	CLEANER HOLDER CLEANER ELEMENT AIR CLEANER COVER SCREW 4X10 S. VASHER 4	1 D D118691- 1 D D118691- 1 D D118691- 2 D D118691- 2 D D118691-
3-034   990-11040-10 3-035   992-01040-01 3-036   425-00700-20 3-037   992-10040-01	L VASHER 4 D CLEANER HOLDER A	2 D D118691- 2 D D118691- 1 D D118691- 2 D D118691-

### FIG.4 RECOIL STARTER




REF	MER PARTER	PARMANE	Š	SERIA NER REMARKS
4-000		RECOIL STARTER ASS'Y	1	1
4-001		RECOIL STARTER BODY		
4-002	783-01006-201		111	
4-003	779-01006-201			
4-004		STARTER ROPE REEL	1   1	
4-005	773-01006-206	PULLEY SHAFT/OUTER		
4-005	814-00500-200	STARTER PULLEY SHIM		
4-007	776-01006-207			
4-008	990-11050-101			
4-009	992-10050-012		[2] [	-H180430
4-009		SWALL WASHER 5		H180431-
4-010	780-01006-201		11	
1 ***	'			
4-011	785-10207-201	STARTER HANDLE	11	ļ.
4-013	992-01060-011	WASHER 6	1	į
4-014	992-10060-012	S. VASHER 6	11	
4-015	991-01080-011	NUT 6	1	
4-016		STARTER HANDLE CAP	1	
4-017	992-01040-011	VASHER 4	1 N	
1				
4-017	992-00040-011	SHALL VASHER 4	1 D	J075261-
4-018	782-00546-200	ROPE RECEIVE	<u>11</u>	

### FIG.5 TANK, CARRYING HANDLE & BASE




<b>€</b>	,		
REF	NER PARTER	PARMANE	SERVATOR REMARKS
5-001 5-002 5-004 5-005 5-006 5-007	591-00573-200 595-00532-900 648-00532-203 607-00532-804	TANK.50:1 TANK CAP ASS'Y FUEL TANK BAND FUEL TANK BRACKET COMP. FUEL TANK CUSHION RUBBER	1 1 2 1 2 D C091881-
5-007 5-008 5-008 5-009 5-010 5-011	990-11050-201 992-01050-011 992-10050-012 990-11050-121 992-10050-012 991-01050-011	VASHER 5 S.VASHER 5 SCREV 5X12 S.VASHER 5	2 N N 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
5-012 5-013 5-014 5-014 5-015 5-016	592-00002-901 992-01050-011	WASHER 5 PET-COCK ASS'Y PET-COCK ASS'Y	2 2 1 1 P -C040394 C040395 -
5-017 5-018 5-019 5-020 5-021 5-022	990-11050-101 992-10050-012 700-05008-095 700-05008-140 090-31200-802 268-30600-201	S.WASHER S FUEL PIPE A FUEL PIPE B HANDLE COMP.	2 2 1 1 1 1 1
5-025 5-026 5-027 5-027 5-030 5-033	990-21060-121 992-10060-012 080-31200-201 080-31223-200 312-31700-201 990-21080-121	S. WASHER 6 BASE ENGINE BED CUSHION RUBBER	2 2 1 1 P -C091880 C091881-
5-034 5-035 5-038 5-041	992-10060-012 680-01004-200 992-01060-011 992-00100-011	CLIP 8	3 2 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
į			

FIG.6 PUMP




/ 4 /	<del></del>	/// / 5
REF. NER PAR	WER PAR WANTE	SERVINER REMARKS
6-001 300-31200- 6-002 160-31200- 6-006 990-11060- 6-007 992-01060- 6-007 992-10060-	-211 COUPLING PLATE -915 MECHANICAL SEAL ASS'Y -281 SCREW 6X28 -011 WASHER 6 -012 S.WASHER 6 -200 INPELLER	1 1 3 3 3 1
6-010 330-31200 6-011 331-31200 6-012 999-67035 6-013 320-31200	-200 VOLUTE CHAMBER -200 CASING -202 CASING COVER GASKET -010 O-RING G-35 -812 SUCTION PLATE COMP800 SUCTION PLATE GASKET	
6-016 999-67025 6-017 021-31200 6-018 999-67015 6-019 990-11060	-210 PRINING PLUG -500 O-RING P-25.5 -200 DRAIN PLUG -000 O-RING P-15 -421 SCREW 6X42 -601 SCREW 6X60	1 1 1 6 3 3 4 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5
6-022 990-11060 6-023 992-01060 6-023 992-10060 6-024 303-00200	-161 SCREW 6X16 -181 SCREW 6X18 -011 WASHER 6 -012 S.WASHER 6 -200 GEAR CASE GASKET A -230 IMPELLER SHAFT SHIM 0.2	4 M 4 13 H 13 1 1 V
B-025 034-31200	-240 IMPELLER SHAFT SHIM 0.3 -250 IMPELLER SHAFT SHIM 0.5 -270 IMPELLER SHAFT SHIM 1.0	V V

### FIG.7 TOOLS & OPTIONAL PARTS



REF	NER PARTIER	PARTUANE	ST SERIANER REMARKS
7-001 7-002 7-002 7-003 7-004 7-005	050-31215-900 132-31200-210 132-31223-200 050-31200-901 170-31200-802	WATER COUPLING ASS'Y VIRE BAND 32 VIRE BAND 33 WATER COUPLING ASS'Y ADJUSTABLE NOZZLE STRAINER COMP.	1
7-006 7-007 7-008 7-009 7-010 7-010	851-20000-201 862-20000-200 180-31200-200 022-31221-200	COMBI. BOX SPANNER 10X19 ,PLUS SPARK PLUG BOX SPANNER PLUS DRIVER 4 SUCTION HOSE NIPPLE 3/4-1 COUPLING 17/16	1 N H114701- 1 D H114701- 1 D H114701- 1 N C223296- 1 R -C223296- 1 C223296-
7-012	054-31200-202	WATER COUPLING GASKET	2

#### FIG.8 MARKS



REF. NER PARTIER	PARTIAME	SERIANDR REMARKS
8-001,1 913-00501-200 S 8-001,2 140-31221-211 S 8-001 950-31221-200 S 8-002 908-04021-200 S 8-003 892-31221-200 S 8-004 906-31221-200 S	IANE PLATE Proforce Mark a Choke Mark Dut put Mark	1 R -G246620 1 -J075260 1 N J075261- 1 N J075261-