


REED SWITCH.

- 2) SWITCH MUST BE ADJUSTED TO OPEN AT APPROXIMATELY 70 DEGREES.
- 3) LO-21 RED AND BLACK WIRES CONNECT TO THE SOLENOID VALVE.

### TITLE: KM 2000 "B" CONTROL WITH EAGLE, **BODYGUARD, SUPERSCANS, INHIBIT RELAY**

SIZE:	CAGE CODE	≣: [	DWG NO:	FILE OF:		DRAWN BY:	REV:
Α			80.0111	ENG'G	i	JED	01
SCALE: NONE D		D/	ATE: 05 J	AN 04	SHEE	T: 1 OF 1	,



NOTES: 1) WIRE LO-21 RED / BLACK WIRES TO MICRO-SWITCH WHEN STACK OR LATCH ASSIST FUNCTIONS ARE TURNED ON. (SEE NOTE 2)

- 2) AN ADDITIONAL MICROSWITCH WILL NEED INSTALLED ON OPERATOR ORIENTED 180 DEGREES FROM CLOSED LATCH SPEED SWITCH. THIS WILL PROVIDE PROPER VOLTAGE TO THE LO21K. CONTACT B.E.A. TECHNICAL SUPPORT FOR WIRING INFORMATION.
- 3) SW-1 SETTINGS (UP IS OFF) 1.PUSH-N-GO 2. LATCH ASSIST 3. RATCHET FUNCTION 4. STACK PRESSURE.
- 4) DUAL CONTROL SHOWN
- 5) SW-1 CALIBRATION SWITCH REMOVE JUMPER AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM




100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com

# TITLE: KM 3100 "K" CONTROL WITH COMMANDER SYSTEM

SIZE:	DRAWN BY: KJG	REV BY: TUC	PART NO: 80.0134.01
Α	SCALE:	DATE:	SHEET
	NONE	23 NOV 2005	1 OF 1





NOTES: 1) SW-1 SETTINGS (UP IS OFF) 1.PUSH-N-GO 2. LATCH ASSIST 3. RATCHET FUNCTION 4. STACK PRESSURE.

2 ) DUAL CONTROL SHOWN


3 SW-1 CALIBRATION SWITCH REMOVE JUMPER AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

TITLE: KM 3000/3100 (MICRO) K-CONTROL LO21K, W/PARALLAX 2 SYSTEM Q-DISCONNECT ON APPROACH SIDE

OILL.	DRAWN BY: KJG	REV BY: TUC	PART NO: 80.0176.02
В	SCALE:	DATE:	SHEET
	NONE	01 DEC 2005	1 OF 1





NOTES: 1) SW-1 SETTINGS (UP IS OFF) 1.PUSH-N-GO 2. LATCH ASSIST 3. RATCHET FUNCTION 4. STACK PRESSURE.

- 2 ) DUAL CONTROL SHOWN
- 3) SW-1 CALIBRATION SWITCH REMOVE JUMPER AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM




100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101

#### TITLE: KM 3000/3100 (MICRO) K-CONTROL LO21K, W/PARALLAX 1 SYSTEM Q-DISCONNECT ON APPROACH SIDE

OILL.	DRAWN BY: KJG	REV BY: TUC	PART NO: 80.0177.02
В	SCALE:	DATE:	SHEET
	NONE	01 DEC 2005	1 OF 1





PRESSURE=(OFF).


- 2) LO21K: DIP SWITCHES 6, 7, 8, NOT USED.
- 3) SW-1 CALIBRATION SWITCH (LOCATED ON CONTROL) REMOVE JUMPER AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS. CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

## TITLE: KM 3000/3100 (MICRO) K-CONTROL LO21K, W/PARALLAX 1 SYSTEM **Q-Disconnect on Safety Side**

	SIZE:	DRAWN BY: TUC	REV BY: TUC	PART NO: 80.0210.01
I	Α	SCALE:	DATE:	SHEET
		NONE	18 OCT 2005	1 OF 1





NOTES: 1) SW-1 SETTINGS (UP IS OFF) 1.PUSH-N-GO(OFF). 2. LATCH ASSIST(OFF). 3. RATCHET FUNCTION(OFF). 4. STACK PRESSURE(OFF).

- 2) LO21K: DIP SWITCHES 6, 7, 8, NOT USED.
- 3) SW-1 CALIBRATION SWITCH REMOVE JUMPER ON CONTROL AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM




FAX: (412) 249-4101 EMAIL: www.beasensors.com

## TITLE: KM 3000/3100 (MICRO) K-CONTROL LO21K, W/PARALLAX 1 SYSTEM **Q-Disconnect on Approach Side**

SIZE:	DRAWN BY: TUC	REV BY: TUC	PART NO: 80.0211.01
Α	SCALE: NONE	DATE: 18 OCT 2005	SHEET 1 OF 1
	NONE	18 001 2005	1 OF 1





 $\Lambda$