

Parts Catalog

ŝ


Brush Cutter

Model: TBC-4110

Part # 27121 12-15-96

TBC-4110 OPTIONS AND ACCESSORIES


NYLON LINE



;

٠

.



TBC-4110 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	·		s	SERIAL NO	REMARKS
6	157-11666-900	CAP,SPARK PLUG ASS'Y	1	-	C		
7	255-04200-200	COVER, SPARK PLUG, RUBBER	1		с		
8	018-01805-200	PLUG,SPARK	1		В		
11	001-0423Z-90	CYLINDER, TBC-4110	1		в		
1	994-61050-184	BOLT,HEX,5X18,S	4		c		
14	017-04230-20	GASKET,CYLINDER			C		
					Ŭ		
15	041-04050-200	BING PISTON	2		Α		
16	030-0423Z-90	PISTON SET	1		A		
17	037-01000-20	PIN,PISTON	-		D		
18	039-05004-200	CIRCLIP, PISTON PIN	2		В		
21	046-04200-80	CRANKSHAFT	1		D		
22	999-62101-004	BEARING,NEEDLE,F1010B			в		
	000 02101-004	BEATING, NEEDEE, TOTOB	'		Ы		
23	991-11100-013				с		
1		PAWL,STARTER ASS'Y			В		
1	072-04203-90				D		Includes besides a transformer
	090-04200-210	CRANKCASE,ASSY	1				Includes bearings, seals & gasket
1		GASKET, CRANKCASE	1		D		
28	999-66152-511	SEAL,OIL,#VE15X25X7	2		A		
29	999-61620-200	BEARING,BALL,#6202	2		В		
20	070.00401.004						
		WASHER, CRANKSHAFT 15X22	2		D	[
		KEY,WOODRUFF,3X13X5		i	D		
		SHIM,15.2X20X.05	1		D		
32		SHIM,15.2X20X.10	1		D		Shims are "as needed" to obtain
32		,	1		D		correct c/s side clearance.
32	071-11600-230	SHIM,16X21X.20	1		D		
					_		
	071-11600-240		1		D		
i	994-14060-451		2		D		
38	994-14060-301		2		D		
40		PAWL,STARTER	1		С		
41	790-0162V-200	SPRING, PAWL, STARTER	1		D		
42	993-55050-000	RING,STOP,5	1		D		
	170 04000 00						
50	178-0423Q-80	WIRE, GROUND	1		С		
51	155-20520-80	ROTOR,MAGNETO	1		D		
52	992-00100-011	WASHER,10	1		D		
	991-11100-011		1		С		
55	167-20505-80		1		C		
56	994-14050-181	SCREW,S,5X18	3		D		
	000 00050 044						
		WASHER, SMALL, 5	3		С		
	159-20505-800		1		С		
60	994-15050-141	SCREW,5X14/PS	2		D		
L							

FIGURE 1 cont.


TBC-4110 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
63	198-05015-800	CLAMP,CORD	1		С		
66	112-04230-20	CASE,FAN	1		D		
67	994-14060-202	SCREW,6X20S	4		D		
68	203-0604A-202	GROMMET	1		в		
69	203-06000-200	GROMMET, PRIMARY CORD	1		С		
82	274-04037-800	CORD,EARTH	1		D		

* Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

;

FIG. 2 ENGINE COMPONENTS



,

.

TBC-4110 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO	REMARKS
. 1	738-04230-200	PROTECTOR, MUFFLER	1		D		
2	994-15050-122	SCREW,5X12/PS	1		С		
3	994-13050-121	SCREW 5x12/P	1		С		
5	990-53060-653	SCREW,HEX,6X65	2		В		1
6	992-01060-011	WASHER,6	2		A		
7	704-0423Z-90	MUFFLER	1		С		
9	751-04200-201	GASKET,MUFFLER	1		С		
10	721-0423Z-90	PIPE,TAIL	1		Α		
	994-14040-081	,	2		D		
		ARRESTER,SPARK	1		С		
14	737-04230-200	GASKET,MUFFLER	1		D		
16	133-04230-20	SHIELD,HEAT	1		С		·
	455-47141-90	CARBURETOR, TBC-4110	1		В		
		SCREW,5X18/PS	2		С		
		SCREW,PS,5X25	2		D		
	653-04200-200		1		D		
	655-06100-200	,	2		А		
27	655-04200-200	CUSHION, FUEL TANK	2		С		
	403-04230-200		1		D		
		INSULATOR,CARB	1		В		
	402-0602K-21	GASKET,CARBURETOR			В		
	453-0637C-200		1		С		
			1		С		
36	423-01380-81	BODY, AIR CLEANER	1		D		
37	528-01380-20						
		VALVE,CHOKE BOARD,BLOW OVER CHECK	1		D D		
		ELEMENT, CLEANER	1 1		A		
	992-04080-030				c		
	452-01380-90		1		C		
42	380-0637C-200	-			в		
76			'				
43	994-14050-571	SCREW.5X57.S	2		С		
	994-16050-241	, ,	2		c		
		PIPE,FUEL,3X5X230	1		c		
	680-00731-201				В		
	675-01630-900		1		A		
	591-04230-200				D		
					-		
75	595-0423Q-90	CAP,TANK	1		A		
76	603-04201-200	BAND,HOLDING,TANK	1		c		
77	652-04201-200	CUSHION	1		С		

FIGURE 2 cont.

TBC-4110 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO.	REMARKS
- 78	994-15050-162	SCREW,5X16/PS	2		С		
81	359-10112-203	WASHER,CLUTCH B	2		A		
82	290-04200-80	SHOE,CLUTCH	2		в		
83	342-04200-200	SPRING,CLUTCH	1		в		
84	358-10112-201	WASHER, CLUTCH	2		A		
85	357-04201-200	BOLT, CLUTCH STEP	2		в		

* Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

:

FIG. 3 RECOIL STARTER





FIGURE 3

•


REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
0	762-04220-90	STARTER, RECOIL ASS'Y	1		С		
1	772-04220-80	BODY, RECOIL STARTER	1		С		
2	769-04220-20	REEL,STARTER ROPE	1		в		
3	779-04220-20	SPRING, RECOIL	1		В		
9	783-04220-20	ROPE,STARTER	1		А		
12	835-04220-20	CAP,HANDLE	1		В		
14	785-04220-20	HANDLE,STARTER	1		С		
15	839-04220-20	SCREW,SET	1	Ì	А		



TBC-4110 PARTS LISTING


REF.	PART NO.	PART DESCRIPTION		С	c	SERIAL NO	DEMARKO
0	455-47141-90		4	Ĕ		SERIAL INU.	REMARKS
-		CARBURETOR, TBC-4110			C		
2	575-25152-80	BODY,PUMP	1				
3	476-25004-200	COVER, DIAPHRAGM	1		D		
4	~~~	*DIAPHRAGM,METERING	1		В		* Contained in Carb. Repair Kit
5	~~~	*GASKET,DIAPHRAGM .78mm	1		D		650-25124-900
6	~~~	*DIAPHRAGM,PUMP	1		в		(Not availiable individually)
							(
7	~~~	*GASKET,PUMP	1		в		
8	599-2000W-47	JET,MAIN # 47	1		Α		
9	550-25100-200	O-RING	1		А		
10	489-25100-200	RING,STOP	1		D		
11	539-25120-200	SWIVEL	1		D		
13	514-25100-200	SCREW, THROTTLE SET	2		D		
14	544-25164-200	STAY,ADJUST,CABLE	1		С		
15	991-01060-013	NUT,6	1		в		
16	614-25137-200	ADJUSTER,CABLE	1		D		
		PACKING, CLEANER	1		С		
	548-25101-200		4		D		
19	549-25165-20	WASHER, THRUST	1		D		
20	~~~	*SCREEN,INLET	1		С		


į.



REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
1	289-04205-801	SHAFT,CLUTCH	1		С		
3	999-61620-202	BEARING,BALL,#6202Z	2		С		
4	993-50015-002	RING,STOP,C-15 EX	1		С		
5	347-04201-20	FLANGE,CLUTCH	1		В		
6	994-14050-161	SCREW,5X16/S	4		С		
9	599-04201-80	CUSHION	1		С		
10	331-04201-200	CASE,CLUTCH	1		D		
11	994-61050-124	BOLT,HEX,5X12S	4		А		
13	990-51050-103	BOLT, HEX. HOLE, 5X10	1		А		
14	282-04201-200	HOLDER, PIPE	1		D		
15	990-53060-453	BOLT,HEX,6X45	1		С		
16	992-10060-062	WASHER,S,6	1		Α		
17	992-01060-061	WASHER,6	1		D		
18	991-91060-061	NUT,SQUARE,6	1		С		

FIG.6 HANDLE






REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO	REMARKS
_ 1	343-37121-20	SHAFT,DRIVE	1		D		
2	341-37101-80	PIPE, DRIVE SHAFT	1		С		
3	347-37100-90	BUSHING ASS'Y	5		D		
26	162-37101-200	SWITCH,STOP	1		в		
27	993-42030-081	SCREW, TAPPING, 3X8	3		D		
28	259-37101-200	BASE,STOP SWITCH	1		C		
						:	
29	262-37101-200	SPRING, STOP SWITCH	1		D		
30	177-37101-200	TERMINAL,EARTH B	1		A		
31	176-37101-200	TERMINAL,EARTH A	1		A		
32	991-86050-000	NUT,LOCK,5	1		D		
33	993-55060-001	RING,STOP,6	1		D		
34	832-37101-200	SPRING,RETURN	1		С		
ĺ							
35	880-37101-200	LEVER,THROTTLE	1		в		
36	994-31050-251	SCREW,S.,5X25	1		С		
37	853-37101-200	SHAFT,LOCK BUTTON	1		D		
38	958-37101-200	SPRING,LOCK,BUTTON	1		D		
39	956-37101-200	BUTTON,LOCK	1		D		
42	335-37121-20	BRACKET,STRAP	1		D		
43		COLLAR, LIFTING METAL	2		D		
1 1		BOLT,HEX HOLE 5x30.P	2		D		
	315-37304-200		1		D		
		GRIP,HANDLE R	1		D		
	165-33130-200		1		С		
64	994-61050-254	BOLT,HEX HOLE,5X25S	4		С		
		BRACKET,HANDLE,B	1		С		
i	507-37121-20	BRACKET,HANDLE,B	1		D		
69	508-33411-20	BRACKET,HANDLE,C	1		D		
	992-10060-062		2		A		
ł !	990-53060-253		2		С		
74	460-33111-900	CLAMP	3		В		
					_		
		HANDLE	2		С		
	178-33691-80	WIRE,STOP	2		С		
1 1	885-37258-80		1		C		
			1		С		
81	164-10083-00	TUBE, PROTECTION 10x30mm	1		D		
		LEVER, THROTTLE ASS'Y	1		В		
91	SS400	STRAP,SHOULDER	1		В		

^{*} Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A-Fast moving B=Med. fast C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part

FIG.7 GEAR CASE



TBC-4110 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO	REMARKS
. 1	300-33392-92	CASE,GEAR,ASS'Y	1		D		
2	993-51028-002	RING,STOP,IN,C-28	1		C		
3	993-50012-002	RING,STOP,C-12 EX	1		A		
4	999-61600-102	BEARING,BALL,#6001Z	1		в		
5	999-61600-100	BEARING,BALL,#6001	1		в		
7	300-33392-21	CASE,GEAR	1		C		
8		BEARING,BALL,#6000	1		C		
	304-37100-21	SHAFT,GEAR	1		A		
1	999-61620-303	BEARING,BALL,#6203D	1		A		
	993-51040-002	RING,STOP,C40	1		C	1	
13	994-61050-254	BOLT,HEX HOLE,5X25S	2		C		
15	994-61050-124	BOLT,HEX,5X12S	1		С		
17		BOLT,HEAD 8x10	1		D		
1		SCREW,5X16/WS	3		D		
21	324-37110-200		2		D		
26	307-37100-81	COVER, PROTECTION	1		С		
27	310-37100-21	HOLDER,CUTTER	1		C		
28	311-33386-20	CAP,CUTTER HOLDER	1		С		
31	312-33386-20	BOLT, FIXING, L.H.	1		С		
	301-37100-00	SET,GEAR/PINION	1		D		
36	990-53060-153	BOLT,HEX,6X15	2		В		
37	992-10060-062	WASHER,S,6	2		Α		
	442-37121-20	BRACKET,COVER 30 DIA	1		С		
	441-37100-80	GUARD,SAFETY	1		С		
51	307-33670-20	PROTECTOR, WINDING	1		С		
		l					

FIG.8 TOOLS & NYLON HEAD






FIGURE 8

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
0	783-33670-93	IR487/AUTO HEAD (L)	1		В		
1	786-33670-92	BODY,CUTTING	1		C		
2	789-33670-23	CAP,BODY	1		в		
3	787-33670-210	REEL,(L)	1		в		
5	314-33670-20	BOLT,8X1.25 LH GOLD	1		Α		
6	792-33004-200	WASHER, REEL	5		Α		
7	790-33004-200	SLIDER,REEL	1		Α		
8	791-33004-200	HOOK,REEL SLIDER	1		Α		
9	673-35600-20	BALL,STEEL	4		Α		
10	793-33910-20	SPRING,REEL	1		A		
11	358-02103-200	WASHER,CLUTCH A	1		Α		
21	788-33670-21	EYELET	1		С		
23	813-20000-200	WRENCH,HEX,4	1		D		
24	826-20000-80	SPANNER,COMBI,17X19	1		c		
25	746108	BLADE,10X80,1R489,(PSB-180)	1				Optional -
26	BP-100	PROTECTOR,BLADE,9/10"	2				Optional
27	308-33410-200	COVER, PROTECTION, B	1		D		
35	948-39907-200	BAG,TOOL	1		D		

FIG. 9 DECALS









REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
1	906-47141-20	DECAL,TBC-4110	1		D		
2	950-31310-200	DECAL, PRO-FORCE A	1		D		
4	923-33700-20	DECAL,LEVEL	1		D		
5	919-37286-20	DECAL,CAUTION	1		в		
6	920-32466-20	DECAL	1		D		
7	951-31310-200	DECAL,PRO-FORCE B	1		D		