Covers All 1175 Series Remote Starters AUTOMATIC TRANSMISSION ONLY!

REMOTE STARTERS





www.ultrastarters.com

Note: Some features may not be available on certain models.

Warning!!

CARBON MONOXIDE MAY CAUSE SERIOUS INJURY, EVEN DEATH! It is the sole responsibility of the user to place the system in Service Mode when parking in an enclosed area *ex: garage*, partially enclosed area *ex: carport*, or when the vehicle is being serviced.

NEVER INSTALL IN A MANUAL TRANSMISSION VEHICLE!!!

Welcome

Congratulations on your purchase of an Ultra Start remote vehicle starter. Ultra Start remote vehicle starters will provide years of comfort and convenience. To utilize and understand this system to the fullest, PLEASE READ THIS MANUAL IN DETAIL.

About Ultra Start

It is our continuing objective to design and manufacture the absolute best Remote Car Starters, Vehicle Security Systems, Keyless Entry Systems and Security Bypass units available in today's competitive market. This objective is met by utilizing installation professionals with decades of industry experience to assist in each step of the design process. This has allowed us to build products that are very installer and user friendly yet offer advanced and innovative features. Our systems utilize intelligent programming and auto learning systems and are designed to work properly in every vehicle. Our systems are also designed wherever possible to be easily enhanced, allowing the consumer and the retailer to enjoy easy and cost effective upgrades and additions to their system down the road. Our limited lifetime warranty provides one of the best protection plans in the industry, giving both the consumer and the retailer confidence when they invest in an Ultra Start product.

Safety

VERY IMPORTANT SAFETY NOTES!

The owner/user MUST INSTALL a <u>CARBON MONOXIDE</u> <u>DETECTOR</u> in the living area near to where the vehicle is being stored or parked. It is the sole responsibility of the owner/user to keep the remote transmitters away from the reach of children and handle with care so that the system does not unintentionally start. When the vehicle is parked in an enclosed/partially enclosed area (ex: garage, car port...), being serviced (ex: oil change) or the vehicle is loaned to an operator not familiar with a remote starter, the system MUST BE placed Service Mode (see page 10).

MANUAL TRANSMISSION STARTERS the installation of a remote starter MUST only be done with a specified manual transmission starter. It is the sole responsibility of the vehicles owner to insure that the vehicle is left with the transmission in neutral position when the remote starter is in use. The manual transmission starter is designed to be an added measure of safety ONLY! The manufacturer does not guarantee or insure against any damages or loss of life that could result in the event of a remote starter starting while the vehicle is in gear. Manual transmission models are designed only to act as a deterrent against the vehicle starting in gear, this is the vehicle's owner's and operator's responsibility.

NEVER OPERATE THE SYSTEM IN AN ENCLOSED/PARTIALLY ENCLOSED AREA!

Remote Starter Functions

Remote Starting (if remote start fails to start see page 15)

- 1. Press and release the START button.
- 2. The park lights will flash and the horn (optional) will honk once to confirm. The vehicle will then remote start, the horn (optional) will honk and the park lights will then flash four times then remain on while the vehicle is running*.

Extended Run Time

- While the vehicle is running with the remote starter, press and release the START button
- The park lights will flash and the siren or horn (optional) will chirp one time to confirm. The system will reset the run time.*

NOTE: Not available with 4 minute run time.

Remote Stop

- While the vehicle is running with the remote starter, press and hold the START button for three seconds. The remote starter will shut down.
- 2.The park lights will flash and the siren or horn (optional) will chirp 2 times to confirm shutdown.

NOTE: Pressing the brake pedal or opening the hood will also shut down the remote starter.

Idle Mode

- 1. While the vehicle is running with key, press and release the START button.
- 2. The park lights will turn on and the siren or horn (optional) will chirp twice.
- 3.Turn the ignition key to the "OFF" position and the vehicle will remain running*.

*Default 15 minutes

Diagnostics

If the remote starter does not activate when the button is pressed the park lights will flash a diagnostic code to indicate what shutdown input has been triggered.

PARK LIGHTS	STATUS LED	DIAGNOSTIC CODE
3 Slow Flashes	LED's On Solid	System Is In Service Mode
4 Slow Flashes	Series of 4 Flashes	Not in Reservation Mode (M units)
5 Slow Flashes	Series of 5 Flashes	Ignition On During Start Attempt
5 Flashes	Series of 5 Flashes	Hood Pin Opened
6 Flashes	Series of 6 Flashes	Brake Pedal Shutdown
7 Flashes	Series of 7 Flashes	Tach Lock-Out(see dealer)

System Service Mode (Valet Mode)

System **Service Mode** will disable the remote starter. This will only effect the remote start portion of the system. The optional lock, unlock and trunk release features will still be operational. When the vehicle is to have any under hood or service work done, the system must be placed into **Service Mode**. This feature may also be used if a transmitter is lost, damaged or if the system malfunctions.

ENTERING SERVICE MODE

- 1. Turn the ignition key to the ON position, DO NOT START!
- Within 4 seconds, press and hold the Program Button (located on the antenna) for 5 seconds or until the siren/ horn (optional) chirps five times.

NOTE: With the ignition key in the OFF position, the LEDs on the antenna will turn on solid to confirm Service Mode. If the 3 button is pressed while the system is in Service Mode the park lights will flash 3 times slowly.

EXITING SERVICE MODE

- 1. Turn the ignition key to the ON position, DO NOT START!
- 2. Within 4 seconds, press and hold the Program Button (located on the antenna) for 5 seconds or until the siren/ horn (optional) chirps two times.

NOTE: With the ignition key in the OFF position, the LEDs on the Antenna will turn off and the remote starter functions will be re-enabled.





ATTENTION:

TO AVOID SERIOUS INJURY, this remote start system must be set into Service Mode before any under hood servicing is started. Service Mode will prevent the vehicle from starting while the vehicle is being serviced. It is the sole responsibility of the vehicle's owner to place the system into Service Mode. The manufacture accepts no responsibility for accidental starting of the vehicle while the vehicle is being serviced.

Remote Transmitter Learn

IMPORTANT! All remote transmitters not programmed at this time will be erased from memory for security.

STEP 1 - Within 3 seconds turn the ignition key to the "ON" position three times leaving "ON" the third time.



STEP 2 - Press and hold the Program Button. The park lights will turn "ON" and the horn (optional) will honk once.

Continue to hold the Program Button, the park lights will turn "OFF" and the horn (optional) will chirp 5 times quickly.

NOTE: If the parking lights do not turn "ON", release the Program Button and turn the ignition to the "OFF" position, wait 5sec and repeat steps 1 & 2.

STEP 3 (Default) - While holding the Program Button, press and release the START button on each of the remote transmitters to be programmed.

Battery Replacement

The transmitter battery should be changed at least once every year to maintain proper operating range. Replace with a quality 23A 12volt Alkaline battery.

Limited Lifetime Warranty

The manufacturer warrants to the original purchaser of their remote starters and alarms, that the product shall be free from defects in material and workmanship. However, should this product be proven to be defective. within a two year period from the original date of purchase, the manufacturer will, without charge to the purchaser (excluding any charges incurred to have the product delivered to the manufacturer), repair or replace any part of the remote starter and/or alarm which the manufacturer agrees to be defective. After the initial 2 year period the manufacture shall repair or replace defective products with a nominal processing fee of \$30.00 USD. All warranties apply to the original purchaser and the vehicle in which it was originally installed ONLY. Repairs or replacement of defective modules shall remain at the discretion of the manufacturer. All other parts. components, accessories and/or optional equipment pertaining to the remote starter and alarm are not included in the manufacturer's warranty. This warranty is non-transferable. Request for warranty service from any Factory Authorized Dealer must be accompanied with the original purchase receipt or have product registered by authorized dealer on manufacturer's website. Failure to comply with any of these conditions may result in warranty being voided. This warranty does not cover the following: removal and reinstall labor charges, shipping charges, abuse, misuse, or accidental damages to the remote starter and alarm, automobile, and/or parts there of. This warranty is void upon modification, repairs, or alterations of any part of the product. The manufacturer does not quarantee or insure against theft of the vehicle or its contents. Alarm models are designed only to act as a deterrent against possible theft. This alarm may qualify for auto insurance discounts, contact your Insurance Agent for further information. The manufacturer shall not be held liable for any consequential damages due to breach of this or any other warranty, expressed, or implied. This warranty gives you specific legal rights. Your specific legal rights may vary for each region.

CERTAIN DAMAGES EXCLUDED - The manufacturer expressly disclaims any liability or responsibility for incidental damages caused by the product, including economic loss, loss of use of the product, car rentals, or any other costs relating to the care and custody of the product. The manufacturer disclaims liability or responsibility for any consequential damages caused by the product or resulting from its use, including the cost of repairing or replacing other property damaged by the product or caused by its use, whether or not the product is working properly. The product is intended to deter unauthorized use of the vehicles in which it is installed. The manufacturer does not warrant that the product is fool-safe against theft and/or vandalism and/or human error or misuse. The manufacturer accepts no liability or responsibility for any damage of any kind whatsoever caused to any vehicle in which the product is installed or any resulting damage from its use. The manufacturer accepts no responsibility or liability for any damage resulting to or theft of the vehicle or its contents, caused or alleged to be caused, directly or indirectly, by failure of the product.

MANUAL TRANSMISSION STARTERS the installation of a remote starter MUST only be done with a specified manual transmission starter. It is the sole responsibility of the vehicles operator to insure that the vehicle is left with the transmission in neutral position when the remote starter is in use. The manual transmission starter is designed to be an added measure of safety ONLY! The manufacturer does not guarantee or insure against any damages or loss of life that could result in the event of a remote starter starting while the vehicle is in gear. Manual transmission models are designed only to act as a deterrent against the vehicle starting in gear, this is the vehicle's owner's and operator's responsibility.