

AM/FM Stereo Headset (120-0921)

Features

Faxback Doc. # 7134

Your Radio Shack AM/FM Stereo Headset Radio with Bass Boost is designed for your active lifestyle. The headset radio provides you with high-quality FM Mono, FM Stereo, and AM reception. With the built-in antenna, you can listen to music, sports, or news anywhere you go.

INSTALLING/REPLACING THE BATTERY

Your headset radio uses an AA battery (not supplied). We recommend an alkaline battery (Radio Shack Cat. No. 23-552/557) for longest life. Follow these steps to install or replace the battery.

1. Press down the tab on the battery compartment cover and slide it in the direction of the arrow.
2. Insert one AA battery inside the compartment as indicated by the polarity symbols (+ and -) marked beside the compartment.
3. Replace the cover.

NOTES: If you do not plan to use the radio for several days, remove the battery.

Replace the battery when the radio's sound weakens.

Your Radio Shack AM/FM Stereo Headset Radio with Bass Boost is an example of superior design and craftsmanship. The following suggestions will help you care for the radio so you can enjoy it for years.

Keep the radio dry. If it gets wet, wipe it dry immediately. Liquids can contain mineral that can corrode the electronic circuits.

Handle the radio gently and carefully. Dropping it can damage the circuit board and case, and can cause the radio to work improperly.

Wipe the radio with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the radio.

Use and store the radio only in normal temperature environments. Temperature extremes can shorten the life of electronic devices, damage batteries and distort or melt parts.

Use only a fresh battery of the required size and type. Always remove an old or weak battery. It can leak chemicals that can destroy the electronic circuits.

Keep the radio away from dust and dirt, which can cause premature wear of parts.

Modifying or tampering with the radio's internal components can cause a malfunction and might invalidate its warranty. If your radio is not performing as it should, take it to your local Radio Shack store for assistance.

AM/FM Stereo Headset (120-0921) Specifications Faxback Doc. # 7137

Power Requirements.....1.5 V
(One AA battery)

Frequency

Range.....AM: 530-1710 KHz
FM: 88-108 MHz

Weight.....4 Oz (Without Battery)

Dimensions.....5 27/32 x 8 13/32 x 2 5/32 Inches (HWD)

(CJD/all-7/12/94)

LN-03/04