


How To USE AND
READ A CALLIPER



USING THUMB-
wheel MOVE SLIDE
OPEN TO OBJECT'S
DIAMETER OR
THICKNESS. READ