

Adding content to Kindles:

1. Turn the Kindle on, hit Home button, then the Menu button.
2. Use down arrow in Navigation Tool to select Settings, then hit center navigation button
3. Under Registration, click on Register
4. Use keyboard to enter the email address and password. Use the Symbol key for numbers and symbols like @. After you enter a symbol, hit the symbol key again to make the symbol window disappear
 - Email: your.name@canyonsdistrict.org
 - Password: password
5. If the Kindle tells you, you need to connect to a Wi-Fi connection:
 - Choose **canyonair**
 - Password: whateveritis
 - Hit down arrow to select Submit button
 - Hit enter
6. Hit the Home button, scroll to the end of the contents list to Archived Items.
7. Look for the book you want to add to the Kindle.
8. Click on the book and it will be added to the Kindle.
9. Deregister the Kindle by hitting the Home button, then the Menu button.
10. Use down arrow in Navigation Tool to select Settings, then hit center navigation button
11. Under Registration, click on Deregister
12. Hit the Home button, then the Menu button, then View next to Wi-Fi settings.
13. Next to **canyonair**, click on **forget**
 - Use delete key to get rid of one letter at a time
 - Back arrow will erase a complete line
 - Use up arrow for capital letters
 - Can enter more than one symbol without leaving symbol window