

ite Inventory

Language: Locating Points not going to move  
Inventory: Measure the building, measure concrete, MS, wall,  
state: two trees, drain, utilities, sprinklers Spacing  
MS: # of Shrubs, Soil type, Site Condition, Perceived uses, views  
into and out of, noise, Sun vs. shade, level grade erosion wind