

# General Purpose Seat Belt Part Numbers

new number	description	General Position
1600013	General Purpose L/S IR Belt, [XL, XXL], 99° 90° RH ELR, web buckle	Driv
1600014	General Purpose L/S IR Belt, [XL, XXL], 99° 90° LH ELR, web buckle	Pass
1600015	General Purpose L/S IR Belt, [XL, XXL], 99° 90° RH ELR, stalk buckle	Driv
1600016	General Purpose L/S IR Belt, [XL, XXL], 99° 90° LH ELR, stalk buckle	Pass
1600017	General Purpose L/S IR Belt, [XL, XXL], 99° 90° RH ELR, web buckle, in pillar	Pass
1600018	General Purpose L/S IR Belt, [XL, XXL], 99° 90° LH ELR, web buckle, in pillar	Driv
1600019	General Purpose L/S IR Belt, [XL, XXL], 99° 90° RH ELR, stalk buckle, in pillar	Pass
1600020	General Purpose L/S IR Belt, [XL, XXL], 99° 90° LH ELR, stalk buckle, in pillar	Driv
1600021	General Purpose L/S IR Belt, [XL, XXL], 75° 90° RH ELR, web buckle	Driv
1600022	General Purpose L/S IR Belt, [XL, XXL], 75° 90° LH ELR, web buckle	Pass
1600023	General Purpose L/S IR Belt, [XL, XXL], 75° 90° RH ELR, stalk buckle	Driv
1600024	General Purpose L/S IR Belt, [XL, XXL], 75° 90° LH ELR, stalk buckle	Pass
1600025	General Purpose L/S IR Belt, [XL, XXL], 75° 90° RH ELR, web buckle, in pillar	Pass
1600026	General Purpose L/S IR Belt, [XL, XXL], 75° 90° LH ELR, web buckle, in pillar	Driv
1600027	General Purpose L/S IR Belt, [XL, XXL], 75° 90° RH ELR, stalk buckle, in pillar	Pass
1600028	General Purpose L/S IR Belt, [XL, XXL], 75° 90° LH ELR, stalk buckle, in pillar	Driv
1600029	General Purpose L/S IR Belt, [XL, XXL], 60° 90° RH ELR, web buckle	Driv
1600030	General Purpose L/S IR Belt, [XL, XXL], 60° 90° LH ELR, web buckle	Pass
1600031	General Purpose L/S IR Belt, [XL, XXL], 60° 90° RH ELR, stalk buckle	Driv
1600032	General Purpose L/S IR Belt, [XL, XXL], 60° 90° LH ELR, stalk buckle	Pass
1600033	General Purpose L/S IR Belt, [XL, XXL], 60° 90° RH ELR, web buckle, in pillar	Pass
1600034	General Purpose L/S IR Belt, [XL, XXL], 60° 90° LH ELR, web buckle, in pillar	Driv
1600035	General Purpose L/S IR Belt, [XL, XXL], 60° 90° RH ELR, stalk buckle, in pillar	Pass
1600036	General Purpose L/S IR Belt, [XL, XXL], 60° 90° LH ELR, stalk buckle, in pillar	Driv
1600039	General Purpose L/S IR Belt, [XL, XXL], 45° 90° RH ELR, web buckle	Driv
1600040	General Purpose L/S IR Belt, [XL, XXL], 45° 90° LH ELR, web buckle	Pass
1600041	General Purpose L/S IR Belt, [XL, XXL], 45° 90° RH ELR, stalk buckle	Driv
1600042	General Purpose L/S IR Belt, [XL, XXL], 45° 90° LH ELR, stalk buckle	Pass
1600043	General Purpose L/S IR Belt, [XL, XXL], 45° 90° RH ELR, web buckle, in pillar	Pass
1600044	General Purpose L/S IR Belt, [XL, XXL], 45° 90° LH ELR, web buckle, in pillar	Driv
1600045	General Purpose L/S IR Belt, [XL, XXL], 45° 90° RH ELR, stalk buckle, in pillar	Pass
1600046	General Purpose L/S IR Belt, [XL, XXL], 45° 90° LH ELR, stalk buckle, in pillar	Driv