



How to set temperature staying at approx. **55 Deg C**

Step-1. Press **SET** and then input the CODE **0089**

PRESS
0089

Step-2. Press **SET** **TWICE** to go to thermocouple type selection

Int Y
out Y

Step-3. Press **<** **TWICE** to select and confirm the K-type thermocouple is used

Int Y
K

Step-4. Press **SET**, **<** and **SET** ONCE to exit

End
Int Y

Step-5. Input 55 (temperature) to set the **SV** value
(Please use **>**, **^** & **<** to input **digits**)

How to set temperature staying between **80~100 Deg C**

Step-1. Press **SET** and then input the CODE **0089**

Step-2. Press **SET** **TWICE** and then also press **<** **TWICE**

Step-3. Press **SET**, **<** and **SET** ONCE

Step-4. Press **SET** and then input the CODE **0001**

Step-5. Press **SET**, **^** and **SET** ONCE

Step-6. Input 80 (temperature) to set **ON**

Step-7. Press **SET**, **^** and **SET** ONCE

Step-8. Input 100 (temperature) to set **OFF**

Step-9. Press **SET** once, and then press **^** **THREE** times

Step-10. Press **SET** to finish