

APPENDIX A : PARAMETER SYNTAX

This appendix defines the syntax of the various parameters used in the control commands, control messages, Line Editor commands and SYSGEN responses described in this Manual. The notation conventions are described in section 1.9.

alphanumeric-character : : = { letter
decimal-digit }

decimal-digit : : = 0|1|2|3|4|5|6|7|8|9

decimal-number : : = decimal-digit

device-name : : = CR0D|LP0F|MT0C|TK0E|TK1E|TY10

disk-number : : = /F0|/F1|/F2|/F3|/F8|/F9|/FA|/FB

file-code : : = /1|/2|/3 /ED|/EE|/EF

file-name : : = ISO-7-character

hexadecimal-digit : : = 0|1|2|3|4|5|6|7|8|9|A|B|C|D|E|F

hexadecimal-number : : = hexadecimal-digit

label : : = letter [alphanumeric-character]

letter : : = A|B|C|D|E|F|G|H|I|J|K|L|M|N|O|P|Q|R|S|T|U|V|W|X|Y|Z

line-number : : = decimal-number

module-name : : = letter [alphanumeric-character]

procedure-name : : = \$||letter [alphanumeric-character]

unit-address : : = 0C|0D|0E|0F|10|1E

userid : : = letter [alphanumeric-character]

utility-name : : = CPLGEN|DUMPA|DMPGEF|DMPGEN|JESPER|OBX|PM6800
PRDUMP|RUM|SUM|SYSGEN|XRF