

APPENDIX E : INDEX

Subject	Page
AB message	7.4.2
AS message	7.4.3
ASG command	3.1.1
	4.1.2
	6.1.1
	6.3.1
	6.6.1
	6.12.2
ASM command	6.9.1
Assembler language	6.12.3
	1.6
BYE command	3.1.1
Catalogue	6.12.4
Catalogued procedure	5.3.2
	1.5.1
	3.2.1
	6.1.1
	10.1.1
CCI	1.2.1
	4.1.2
Computer Full Panel	6.1.1
Control commands	2.1.1
	1.2.1
	6.1.1
Control command reference	6.12.1
Control messages	1.2.1
	7.1.1
CPLGEN utility	9.2.1
CREDIT language	1.6
	3.1.1
Cylinder number	5.1.1
DCU command	2.5.1
	5.3.3
	6.4.1
	6.12.5
DEL command	3.1.2
	5.3.2
	5.4.2
	6.7.1/2
	6.12.6
Device names	4.1.1
Disk commands	6.7.1
Disk files	3.1.1
Disk numbers	2.4.1
	4.1.1
	4.2.1

Subject	Page
Disk structure	5.1.1
DLU command	2.4.1
	5.3.3
	6.4.1
	6.12.7
DMPGEF Utility	9.3.1
DMPGEN utility	9.4.1
DOS6800 System Software	1.1.1
DUF command	6.7.1
	6.12.8
DUMPA utility	9.5.1
End of file Mark	6.3.1
FBS command	6.8.1
	6.12.9
FFS command	6.8.1
	6.12.10
File assignment	3.1.1
File code table	4.1.1
	4.1.3
	6.6.1
File code commands	6.6.1
File codes	4.1.1
File names	3.1.2
File types	3.1.1
	5.4.2
Granule allocation table	5.3.2
Granules	5.2.1
INC command	3.1.2
	6.3.1
	6.7.1/2
	6.12.11
Input commands	6.3.1
INT : PROD file	3.2.1
JESPER utility	9.6.1
Keeping files	3.1.2
KPF command	3.1.1/2
	5.3.2
	5.4.2
	6.7.1/2
/L file	6.12.12
	3.1.1/2
	4.1.1/2
	6.3.1
	6.6.1
	6.7.1
LED command	6.9.1
	6.12.13

Subject	Page
Library	3.1.1 5.3.2 6.7.1
LIC command	2.4.1 6.4.1 6.12.14
Line Editor	8.2.1
Linkage Editor	8.3.1
LKE command	6.9.1 6.12.15
Load file / module	3.1.1
LSD command	3.1.2 6.7.1 6.12.16
LSF command	6.6.3
LST command	6.12.17 3.1.2 6.7.1 6.12.18
Magnetic tape & cassette commands	6.8.1
Maximum configuration	1.8.1
MES command	6.9.1 6.12.19
Minimum configuration	1.7.1
Monitor	1.2.1 3.2.1
MOV command	6.7.1 6.12.20
Non typewriter commands	6.9.1
Notation conventions	1.9.1
/O file	3.1.1/2 4.1.1/2 6.3.1 6.6.1 6.7.1/3
/OB	3.1.2 4.1.1/2 6.7.1
Object file	3.1.1
/OBJECT	3.1.2 4.1.1/2 6.7.1/3
OBX Utility	9.7.1
Output commands	6.4.1
PCH command	3.1.2 6.4.1 6.12.21
Permanent files	3.1.1/2 6.7.1
PLB command	6.8.1 6.12.22

Subject	Page
PLD command	6.4.1
PM6800 utility	6.12.23
POB command	9.8.1
	6.4.1
PRC command	6.12.24
	2.4.1
	6.4.1
PRD command	6.12.25
	3.1.2
	6.7.1
PRDUMP utility	6.12.26
Processor & utility commands	9.9.1
Processors	6.9.1
	1.3.1
	3.2.1
Program development	8.1.1
PRT command	1.5.1
	3.1.2
	6.7.1
PSE command	6.12.27
	6.9.1
RBS command	6.12.28
	6.8.1
RD message	6.12.29
RDA command	7.4.4
	3.1.1
	6.3.1
	6.4.1
RDO command	6.12.30
	6.3.1
	6.4.1
RDS command	6.12.31
	3.1.1/2
	6.3.1
	6.4.1
REF command	6.12.32
	6.8.1
REW command	6.12.33
	6.8.1
RFS command	6.12.34
	6.8.1
RS message	6.12.35
RSU command	7.4.5
	2.4.1
RUM utility	6.12.36
	9.10.1

Subject	Page
RUN command	6.9.1
RY message	6.12.37
/S file	7.4.6
	3.1.1/2
	4.1.1/2
	6.3.1
	6.6.1
	6.7.1
SAG userid	2.5.1
	3.2.1
	5.3.2/3
	5.4.1
	5.8.1
SCR command	3.1.1
	5.3.2
	6.6.2
	6.7.1
	6.12.38
Sectors	5.1.1
Session	1.2.1
Sign-on/off	1.2.1
SKF command	6.12.39
Source input format	6.3.1
Source file	3.1.1
Special key-ins	1.10.1
Standard file codes	4.1.2
SUM utility	9.4.1
Supervisor	1.2.1
	5.5.1
	5.8.1
SVD command	6.7.1
	6.12.40
SVU command	6.7.1
	6.12.41
SYSGEN utility	9.12.1
System disk	2.1.1
System files	3.2.1
	5.8.1
System Operators Panel	2.1.1
System Session	2.4.1
	3.2.1
System start	2.1.1
Temporary files	3.1.1/2
	6.7.1
TLK command	6.9.1
	6.12.42
TOSS System Software	1.1.1

