












SERIES 5 QUICKSTART

PRODUCT SHOWN IS 520 SPEAKER.



PACK 1787
1/2





DO NOT ATTEMPT TO LIFT SPEAKER ALONE.
ALWAYS LIFT WITH 2 PEOPLE.
SUPPORT SPEAKER AT BOTH ENDS
WHILST TILTING.





ALWAYS LIFT BY THE METAL BASE,
NOT BY THE GLASS PANEL.



FOR ADDITIONAL STABILITY,
SPEAKER MUST BE FITTED
WITH ANTI-TILT BAR.
(520 SPEAKER ONLY)



REMOVE TRANSIT SCREW
M6 x 40 (YELLOW TAG)



CONSULT YOUR LINN SPECIALIST FOR
CONFIGURING THE LOUDSPEAKERS
THROUGH KONFIG.








LINN

SERIES 5 QUICKSTART



PRODUCT SHOWN IS 520 SPEAKER.

PLEASE ALSO REFER TO
www.linn.co.uk/guide


PACK 1787
2/2



REMOVING THE COVER



PULL THE BOTTOM EDGE OF
THE ARRAY TRIM TO REMOVE



DO NOT PULL ON THE FABRIC
TO REMOVE THE ARRAY TRIM

FABRIC COVER CARE INSTRUCTIONS:

DO NOT WASH
DO NOT DRY CLEAN
WIPE WITH DAMP SPONGE
NO DETERGENT
DO NOT TUMBLE DRY
DO NOT VACUUM OVER OR AROUND ARRAY TRIM
USE LINT ROLLER TO REMOVE DUST