

Turning off the Projector Filter Warning



1. Make sure your computer is hooked to the USB port which connects it to the board.
2. In Windows 7 you will need to click the up arrow located in the bottom right corner of




the screen. Then you should look for the Promethean Icon.

3. Not in Windows 7, the icon should still be located in the same place but you may not have to click the up arrow. Instead it may be an arrow pointing left.



4. Once you find the Promethean Icon, click it and choose CONTROL PANEL.



5. After clicking Control Panel you will need to select the Projector Tab and uncheck the Projector Warning box. Do this as many times as it takes to remove the check mark from the box (probably 2 times). Both times you will get a warning notice, just click YES to ignore.

