

Printing the Board

You can print an image of the board at any time using a printer that is connected to the computer.

To print an image of the current board:

- Walk-and-Talk models: Press Print on the remote control.
- TS and LT models: Tap the Print icon on the whiteboard icon strip or in the projection toolbar.
- IRP and IPD models: Tap the Print icon in the projection toolbar.

The whiteboard sends an image of the board to the printer using the current "Print Setup" settings in the Webster software.

Capturing a Snapshot of the Board

The Webster software records all the activity on the whiteboard.

To capture a snapshot image of the current board that you can save or use on the computer:

- Walk-and-Talk models: Press the Save button on the remote control.
- TS and LT models: Tap a Snapshot icon on the whiteboard.
- IRP and IPD models: Tap a Snapshot button in the projection toolbar.

The Webster software captures an image of the current board and adds it to the Webster file that is open. You can continue writing on the board, or erase and continue.