

Initial Housing Unit

Features:

- A) Mounting tabs on the base and back are sized and spaced for 6-32 screws
- B) Simple housing unit cover is bolted on top for easier access
- C) Hole for the potentiometer

