



## FrSky firmware ROM update files

### Introduction:

Frsky are committed to ongoing development. In order to enjoy the benefits of the latest released two way radio system, we invite Frsky users to upgrade your equipment at no cost. We currently provide you the following firmware ROM update files for your reference.

### Details:

**1) fdd\_rx\_rom\_build\_100621.frk:** FrSky two way receiver's firmware ROM file;

**2) host\_roma\_build\_100825.frk:** FrSky two way transmitter modules' acquiescent failsafe version.

To set failsafe position, press briefly (less than 1 second) the "F/S Range" button of the receiver, the Tx module will make a long "beep" indicating the failsafe position is remembered by the receiver;

**3) host\_romb\_build\_100825.frk:** Provided for users to upgrade FrSky two way transmitter modules' failsafe version. In this case, you can set failsafe position on the Tx module at any time during your flight.

**Option1:** To set failsafe positions, press briefly(less than 1 second) the "F/S Range" button of the Receiver, the Tx module will make a long "beep" indicating the failsafe position is remembered by the receiver.

**Option2:** To set failsafe position, press briefly (less than 1 second) the "F/S Range" button of the Tx module, the Tx module will make a long "beep" indicating the failsafe position is remembered by the receiver.

**Note:** Please kindly note that if you accidentally press the "F/S Range" button of the Tx module during your flight, you will change the failsafe state inadvertently.