


Easy Interactive Tools

Toggle between the two modes
using the buttons at the top of
the toolbar

Interactive Mode

In interactive mode, the toolbar appears on the projected image and lets you use the pen as a mouse to open applications, access links, and operate scroll bars, for example.

In this mode, you can also annotate whatever is displayed from your computer or document camera and save or print your pages.



Whiteboard Mode


In whiteboard mode, the toolbar appears on a blank surface, background image, or pattern. You can write or draw with the pen, add images, and save or print your pages.

Annotating


You can use the annotation tools at the bottom of the toolbar in either mode.

Interactive Mode


Whiteboard Mode



THE TOOLS



THE PEN



You can use the pen as a mouse on the projected image using the Easy Interactive Driver software. Press the button on the pen to test the battery. If the light is green, the battery has enough power.

Tips for using the pen as a mouse:

- Hold the pen at an angle, rather than perpendicular to the board
- To left-click, tap on the board
- To right-click, hold down the button while tapping
- To double-click, tap twice
- To click and drag, tap and drag with the pen