

## **Programming the ResponseCard IR**

Set Response Card to a Programmable ID:

1. Press and hold the “\*” and “6” buttons simultaneously for 3 seconds. LED will turn solid red to indicate the process was performed correctly.
2. Enter the number you would like to program the ResponseCard with waiting for the LED to flash after each digit of the number entered. i.e. – if you would like to set the ResponseCard to the number 32, perform the process in Step 1 above and press the number 3 (the LED will flash to indicate digit was programmed), then enter the number 2 (the LED will flash again to indicate the next digit was programmed).
3. Press the “\*” button and the LED will flash 3 times to indicate that the ResponseCard was successfully programmed to a numeric value

Set ResponseCard to its fixed ID:

1. Press and hold the “\*” and “1” buttons simultaneously for 3 seconds. LED will turn solid red to indicate the process was performed correctly.
2. Let go of both buttons and the LED will flash 3 times to indicate that the ResponseCard was successfully programmed with its fixed ID (serial number on the back of the keypad).

