

U3A MAC USERS GROUP

Introduction to your Macintosh Computer

THE OUTSIDE

1. The slots and ports

13-inch MacBook Pro



15-inch MacBook Pro




17-inch MacBook Pro



MACBOOK PRO 15"

I/O Ports




The ports (left side, back to front) and what they do	
MagSafe power port	Plug in the included 85W or 60W MagSafe Power Adapter to recharge the MacBook Pro battery.
Gigabit Ethernet port (10/100/1000Base-T)	Connect to a high-speed Ethernet network, a DSL or cable modem, or another computer. The Ethernet port automatically detects Ethernet devices and doesn't require an Ethernet crossover cable.
One FireWire 800 port	Connect high-speed external devices, such as digital video cameras and storage devices. Connect an adapter or cable to use this port as FireWire 400, FireWire 200, or FireWire 100.
Mini DisplayPort (video out)	Connect to an external display, projection device, or TV that uses a DVI or VGA connector with a separate adapter. You can purchase adapters for supported video formats from Apple.
Two high-speed USB (Universal Serial Bus) 2.0 ports	Connect a modem, iPod, iPhone, mouse, keyboard, printer, disk drive, digital camera, joystick, and more to your MacBook Pro. You can also connect USB 1.1 devices.
SD card slot	Easily transfer photos, videos, and data to and from your MacBook Pro with an SD card.
Audio line in/optical digital audio in port	Connect your MacBook Pro to a line-level microphone or digital audio equipment.
Headphone out/optical digital audio out port	Connect external speakers, headphones (including iPhone), or digital audio equipment.

Note: The security slot is on the right side of the computer, near the optical drive.

MACBOOK PRO 13"

I/O Ports



The ports (left side, back to front) and what they do	
MagSafe power port	Plug in the included 60W MagSafe Power Adapter to recharge the MacBook Pro battery.
Gigabit Ethernet port (10/100/1000Base-T)	Connect to a high-speed Ethernet network, a DSL or cable modem, or another computer. The Ethernet port automatically detects Ethernet devices and doesn't require an Ethernet crossover cable.
One FireWire 800 port	Connect high-speed external devices, such as digital video cameras and storage devices. Connect an adapter or cable to use this port as FireWire 400, FireWire 200, or FireWire 100.
Mini DisplayPort (video out)	Connect to an external display, projection device, or TV that uses a DVI or VGA connector with a separate adapter. You can purchase adapters for supported video formats from Apple.
Two high-speed USB (Universal Serial Bus) 2.0 ports	Connect a modem, iPod, iPhone, mouse, keyboard, printer, disk drive, digital camera, joystick, and more to your MacBook Pro. You can also connect USB 1.1 devices.
Headphone out/optical digital audio out port	Connect external speakers, headphones (including iPhone), or digital audio equipment. You can specify audio analog line in functionality, which supports line-level microphones and audio equipment, by selecting Audio In in the Sound pane of System Preferences.
SD card slot	Transfer photos, videos, and data to and from your MacBook Pro with an SD card.

Note: The security slot is on the right side of the computer, near the optical drive.