



MARSHALLING SIGNALS HELICOPTERS



HOVER



LAND



FIRE




MOVE HORIZONTALLY
LEFT



ENGAGE ROTOR




MOVE HORIZONTALLY
RIGHT



MOVE UPWARDS



DEPART IN THE
DIRECTION SHOWN



MOVE DOWNWARDS