








FLIP CHART STAND



Use D Shape Carabiner. About
 3cm in diameter.
 These go through the
 top holes and also hold
 the charts



Fig 1



When not in use, fold
 over and slip cord into slot
 so that second knot holds
 the covers flat

