

Q I have a PC running Windows8 and will use the Logitech 920 Camera. Any suggestions?

A

For Windows 8 make sure you install the correct drivers and Logitech Webcam Software under the Downloads tap on the Logitech C920 Support site .

<http://www.logitech.com/en-us/support/hd-pro-webcam-c920>

I notice the Logitech Support site now says this in regards to using the C920 on Windows 8 -

"If you want to take advantage of the new Windows 8 interface, look for the **Logitech Camera Controller available at the Windows 8 Store**. (This feature only works with these webcams: C170, C270, C310, C525, C615 and **C920**.)"

<http://apps.microsoft.com/windows/en-us/app/logitech-camera-controller/02b3d909-8b3f-49e1-8928-6a92f53e5217>

Designed for Logitech webcam models: **c920, c615**, c525, c310, and c270.

Features

- **Digital zoom, pan and tilt:** Capture the right frame with ease.
- **Advanced webcam settings: Easily control autofocus, exposure, white balance and more.**
- Auto noise-cancellation: Minimizes background noise for better sound clarity so your words come through loud and clear.
- Face tracking: Intelligent software detects and tracks your face so you'll always be in the picture.
- And more.