


# Toshiba TLP-S10U - SVGA LCD

## Projector Manual - "new to me info" .

Lauretta Cortez

### Air filter cleaning

The air filter prevents dust and debris from getting inside the projector. Never run the projector with the filter removed. It is recommended that the air filter is cleaned regularly.

- The icon message  "Check the air filter for dirt." is displayed every 100 hours. (If the usage time exceeds 100 hours, this message is displayed for 30 seconds when the image is displayed for the first time after power is turned on. This display will be dismissed with any operation.)
- Check out the filter and any debris is found, use the following procedure for cleaning.


#### **WARNING**

- Request cleaning and maintenance of a ceiling-mounted unit from your projector dealership.

#### **1 Unplug power cord.**

#### **2 Remove the air filter.**

Pull out the air filter by taking the catch shown in the figure.




#### **3 Clean the filter.**

Carefully remove the dust and dirt from the air filter with a vacuum cleaner or the like.



#### **4 Replace the air filter.**



Amount of usage hours

Location of air filter