

DHC-MD500/RX707

SERVICE MANUAL

- DHC-MD500/RX707 is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to it.

US Model
Canadian Model

DHC-MD500

AEP Model

UK Model

DHC-RX707

COMPONENT MODEL NAME FOR DHC-MD500/RX707

| | | |
|-----------------------------|-----------|-----------|
| | DHC-MD500 | DHC-RX707 |
| MINI Hi-Fi COMPONENT SYSTEM | HCD-MD500 | HCD-RX707 |
| MINI DISC DECK | MDS-S707 | |
| SPEAKER SYSTEM | SS-RX707 | SS-RX707 |

•Abbreviation

CND : Canadian model
G : German model

SPECIFICATIONS

General

Power requirements

DHC-MD500: 120 V AC, 60 Hz
DHC-RX707: 230 V AC, 50/60 Hz

Power consumption

DHC-MD500: 140 watts
DHC-RX707: 140 watts

Dimentions (w/h/d) Approx. 280 x 335 x 380 mm
(13¹/₃ x 11¹/₃ x 15 in.)

Mass

DHC-MD500: Approx. 8.8 kg (19 lbs. 6 oz.)
DHC-RX707: Approx. 9.1 kg (20 lbs. 1 oz.)

Supplied accessories

AM loop antenna (1)
Remote RM-SR707 (1)
Batteries (2)
FM lead antenna (1)
Speaker cords (2)
Front speaker pads (8)
Connection cord (2) (US,Canadian model)
Optical cord (1) (US,Canadian model)

Design and specifications are subject to change without notice.

PARTS LIST

| Ref.No. | Part No. | Description | Remark |
|--|----------|--|--------|
| ACCESSORIES & PACKING MATERIALS ***** | | | |
| 1-475-806-11 | | COMMANDER,STANDARD (RM-SR707) | |
| 1-501-374-11 | | ANTENNA, LOOP | |
| 1-501-659-41 | | ANRENNNA (FM) (US,CND) | |
| 1-501-804-11 | | ANTENNA (FM) (AEP,UK,G) | |
| 1-776-263-51 | | CORD,CONNECTION (MDS-S707) (US,CND) | |
| 1-574-254-11 | | CORD,LIGHT PLUG (MDS-S707) (US,CND) | |
| 3-862-832-11 | | MANUAL,INSTRUCTION (MDS-S707) (US,CND) (ENGLISH,FRENCH) | |
| 3-864-057-11 | | MANUAL,INSTRUCTION (DHC-MD500) (US,CND,AEP,UK) (ENGLISH) | |
| 3-864-057-21 | | MANUAL,INSTRUCTION (DHC-RX707) (AEP) (FRENCH,SPANISH) | |
| 3-864-057-31 | | MANUAL,INSTRUCTION (DHC-MD500) (CND,AEP) (FRENCH) | |
| 3-864-057-41 | | MANUAL,INSTRUCTION (DHC-RX707) (G) (GERMAN) | |
| 3-864-057-51 | | MANUAL,INSTRUCTION (AEP) (DHC-RX707) (DUTCH,ITALIAN,PORTUGUESE) | |
| 4-981-643-21 | | COVER,BATTERY (FOR RM-SR707) | |

MINI Hi-Fi COMPONENT SYSTEM

SONY®

