

MDX-40

SONY

SERVICE MANUAL

US Model
Canadian Model
AEP Model
UK Model
E Model

CORRECTION - 1

Fill this Correction with the Service Manual.

Subject :


1. DISASSEMBLY
2. EXPLODED VIEWS

(RPC-97014)


 : Changed portion

1. DISASSEMBLY (Supplement-1 see page 2)

1-1. COVER (MAIN), BRACKET L/R



1-2. COVER (ZN) ASSY



2. EXPLODED VIEWS (Service Manual see page 25 and Supplement-1 see page 36)

